

G-scan3

PART REPLACEMENT MANUAL

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Preparation

Chapter 1. Preparation

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure


Preparation

1. Tools and Equipment

- A. Screw Driver (medium: +)
- B. Automotive Trim Removal Tool (small)
- C. Tweezer

* Additional Recommended Tools

- A. Anti-static gloves
- B. Power supply (12V 3A or more)
- C. Warranty void seals



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

Chapter 2. Disassembling the Front Case


This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

2.1. Remove the Stylus Pen



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

1.2. Unscrew the 2 screws from battery cover



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation of this document is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

2.3. Disconnect the connector inside and remove the battery



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

2.4. Remove the “warranty void seal”

** Warranty void if the seal is broken



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practices and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

2.5. Unscrew the 4 screws (M3*10)



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

2. Case Opening

2.6. Use “trim removal tool” to gently open up each corner of the case





* Too much tension on prying action may damage the LCD while disassembling the front case.

Repair Procedure

Disassemble

2. Case Opening

2.7. Widen up the top and bottom, and remove all the FPCB cables from LCD and Touch Panel.



** An individual LCD module itself cannot be replaced. Only the front case assembled with LCD shall be replaced at one go.

Repair Procedure

Disassemble

Chapter 3. LCD Replacement

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.



Repair Procedure

Disassemble

3. LCD Replacement

- 3-1. Put the new LCD in place following the reversed procedure.
- 3-2. When connecting the F-PCB cables, make sure the wires must be aligned on the line

- * Kapton tape should be re-attached after replacing the LCD
- * Make sure not to bend the LCD F-PCB cable
- * Power on and see if the LCD is working correctly.



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

Chapter 4. Disassembling the VCI & Main Board

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure





Disassemble

4. Disassembling the VCI Board

4.1. Unscrew the 7 screws

4.2. Detach the F-PCB cable and 6P connector to remove the VCI board

** VCI board must be replaced in case the “tackle buttons” doesn’t work.



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.



Repair Procedure

Disassemble

4. Disassembling the Main Board

4.3. Remove all the connectors on main board

4.4. Unscrew the 6 screws and detach the board



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble

Chapter 5. Disassembling small parts

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.



Repair Procedure

Disassemble

5. Disassembling small parts

5.1. Entirely remove the double-sided tape

around MIC, Antenna, Speaker before detaching the parts



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Disassemble


5. Disassembling small parts

5.2. Remove the Flash Module first, when replacing the new camera.

* F-PCB cable must not have any cracks

5.3. Remove the VCI board first, when replacing the new keypad.

* Tighten the new keypad to holes correctly



This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and not disclosed to the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.

Repair Procedure

Assemble

Chapter 6. Assembling

This GIT-EZDS Aftermarket Distributorship Manual contains important information on the sensitive business practice and confidential business facts and figures that must be kept confidential and protected from the third party's unauthorized approach. Duplication, photo copy, reproduction or translation to the other language is strictly prohibited without GIT and EZDS prior written consent, and any violation of such prohibition will entitle GIT or EZDS to terminate the distributorship contract.


Repair Procedure

6. Assembling

6.1. Insert the connector side USB port first when assembling the mainboard

6.2. Carefully align 2 screw holes on the VCI board and rear case of housing, and check tackle buttons & key pads position as shown below.

* Do not put too much pressure on each part to be over torqued




Repair Procedure

6. Assembling Front Case

- 6.1. Parallel up the touch pad and LCD F-PCB board to assemble in correct line.
- 6.2. Bottom of the front case should be slide in first and then clip the top part of case

* Make sure the F-PCB board to be cleaned and do not put too much pressure on the parts to be over torqued.



Repair Procedure

END of Document