



封面



Menu Navigation				
Level 1 Menu	Level 2 Menu	Level 3 Menu	Function Description	
Show	Number	Show		
1	8	Scrambler	Open Turn on scrambling mode	
			Close Turn off scrambling mode	
	9	Intercom Beep	Close No beep	
			Start Launch with beeps	
			End Receive with beeps	
2		Both	Transmit and receive with beeps	
	1	CTCSS	67.0HZ-----254.1HZ D023N-----D754N	Transmit and receive change all the time slots (to modify, press → key to select the arrow → time slot and digital sub-tone positive code digital sub-tone inverses code)
	2	Receive CTCSS signal	67.0HZ-----254.1HZ D023N-----D754N	Modify receive subsonic only
	3	Launch CTCSS signal	67.0HZ-----254.1HZ D023N-----D754N	Only modify the launch subsonic
	4	Frequency hopping A	Open Close	
3	5	Frequency hopping mode	Frequency hopping A Frequency hopping B Frequency hopping C	
	6	Learning mode ITI	Open Close	
	Channel Storage	1	storage channels	The intercom couldn't work when the frequency points are the same in different modes
		2	delete channels	
3	Scanning			
3	Option Settings	SS 105 15S	Close Always on	

12

<h2>Warranty card</h2>	
Models _____	Purchase Date _____
Serial number _____	
Seller _____	Contact Number _____
User Name _____	Contact Number _____
Address _____	Zip Code _____

Warranty Description:

1. This warranty card is kept by the customer as a warranty certificate, and will not be replaced if lost.
2. This card take effect only if be stamped and dated by the point of sale.
3. This card is not allowed to be altered. Please confirm that the serial number of the warranty card is consistent with the number of the purchased machine, otherwise it will be invalid.
4. The warranty period is one year. The charger, battery, lanyard, antenna and feeder are consumables and are not covered by the warranty.
5. Users can choose the following ways to obtain maintenance services:
 - a. At the shop where you bought it.
 - b. At the special local maintenance point of our company.