

## JOYPAD UPDATE STEPS

### Applicable Model:



Model: 5088

**ABXY Button: engraved**

Page: 2-3



Model: 5088

**ABXY Button: printed**

Page: 4-5



Model: 5099

**ABXY Button: engraved**


Page: 2-3

## Please complete these steps (5088 or 5099 with engraved abxy buttons)


**Step 1:** Find out your model, download the correct one in drop box link

<https://www.dropbox.com/sh/jvjmzews0co9qh/AAAzj1BpTeZIFefQSaFGiiVZa?dl=0>

**Step 2:** Download and unzip the file



**Step 3:** Choose update program (switch\_XXXX\_fw.exe), then select the corresponding driver (Left or Right)




**Step 4:** Long press 3D joystick around 8 seconds to enter upgrade mode (5 seconds, 1<sup>st</sup> and 3<sup>rd</sup> light will light up, then they go off after extra 3 seconds)




**Step 5:** Connect (L/R) joy pad to PC via micro usb



**Step 6:** Device status of update program will change to online from offline



**Step 7:** Click download to complete updates



## Please complete these steps (5088 with printed abxy buttons)

**Step 1:** Find out your model, download the correct one in drop box link

<https://www.dropbox.com/sh/jvjmzews0co9qh/AAAzj1BpTeZIFefQSaFGiiVZa?dl=0>



**Step 2:** Download and unzip the file

 5088.hex	2020/4/18 13:58	HEX 文件	126 KB
 BM-827.exe	2019/8/24 19:37	应用程序	2,519 KB

**Step 3:** Choose update program “BM-827.exe” and select “5088.hex”





open it



**Step 4:** Long press SL and do not release, then connect controller to computer via usb. LED 1 and LED 3 will light on.



**Step 5:** After it is recognized, click “OK” to start.



Notice: If update failed, press “sync” button to restart controllers and try again.