

FW600 Software upgrade steps

1. Firstly, Prepare a USB disk and OTG adapter cable (the U-disk format must be "FAT32").



- 2 Connect the USB disk to the computer. Store these two softwares: (BSYS6PV.bin)(BSYS6PF.bin) in the root directory of the U disk. Make sure two softwares are (BSYS6PV.bin)snd (BSYS6PF.bin), as shown in the figure below.



- 3 Power on the FW600, and then plug the U disk in.



⚠ Never power off or unplug the USB flash disk during the upgrade process. Otherwise, it won't work.

- 4 Upgrade steps:

- 1 Select system settings
- 2 Select upgrade
- 3 Click OK and wait until the processing bar has finished loading, and then power off and restart.




After the upgrade is completed, please reboot the FW600, select: system settings → system status, and "S6P1.8 200619" is displayed at the lower right corner to indicate that the upgrade is successful.

FW600软件升级步骤

- 1 准备一个U盘和OTG转接线 (U盘格式一定要是“FAT32”)。



- 2 将U盘接入电脑,然后把《BSYS6PV.bin》和《BSYS6PF.bin》两个软件复制(拷贝)在U盘目录里。



- 3 将NEEWER《FW600》开机后再插上U盘。



⚠ 升级过程请勿断电或拔出U盘,否则开不了机。

- 4 升级系统步骤

- 1 选择系统设置
- 2 选择升级
- 3 点击确定



升级完成重新开机后,选择系统设置→系统状态,右下角显示 S6P1.8 200619为升级成功。