


# SIM Card Personalize Tools User Manual




## 1. Card Reader Install:

Our card reader is CCID card reader, so it is plug and play. When you plug it in the USB port of your computer, the Windows system can find it and install the driver automatically. When Card reader install success, you can find the reader name on software screen Reader(PC/SC) box.

## 2. Software Install:

The files in the folder:



Personalize tools no need install, you can copy it into your disk, like Disk D, and double click "GRSIMWrite.exe", then it can run.

### 3. Software user manual:

When the reader and software install success, as the above screen snap, then you can read and write card as below:

1. Choose the right Reader, if there's no reader in the text box, you can plug the card reader again and push button "Refresh"

2. Insert one card into reader, then push "Read Card" button, the data can be read out from the card. If it is our card, it will show the card type in the middle of the screen in "TYPE" area.

NOTE:

KI and OPC cannot be read out, so you cannot clone your original sim card with our software.

3. Input all the parameter like ICCID, IMSI, KI, OPC and others, then push "Write Card" button, software will write card.

4. If the card is not our card, it cannot be written by our software, the software will show error. The reason maybe:

A. The software is too low, cannot write new card, please visit:

[https://smacarte.com/wp/grsimwrite\\_download/](https://smacarte.com/wp/grsimwrite_download/) to check and download new software.

B. Card is not our card, please connect with your card supplier.

### 4. System Requirements :

A : Windows 7 and above.

B : Not support iOS and Linux.

If you need any help, please connect us by Support email: [info@gialer.com](mailto:info@gialer.com).

Smacarte Co., Ltd

10<sup>th</sup> Jan.2016