



How to set my device as default?

1. Search for "**Control panel**" in the lower-left corner, open the control panel, and select "**Hardware and Sound**".




2. Select "**Manage audio device**" in sound.




3. Set EMEET device as the default microphone

- Click the **Recording** tab on the top of the displayed setup window.
- Under the Recording tab, select **EMEET CXXX**, and then click the "**Set as Default device**".



4. If you want to adjust the microphone volume
Double click the microphone **EMEET CXXX** and click "**levels**".
Drag the slider to the volume level you want, and click "OK" to save the changes.



5. Set EMEET device as the default speaker

Kindly remind: Only C980 Pro, C990, Jupiter has the speaker, which can be selected as the output device.

- Click the **Playback** tab on the top of the displayed setup window.
- Under the Playback tab, select **EMEET CXXX**, and then click "**Set as Default device**".
- Click **OK** to save your changes.

