KINVOCA C25 UPDATE FIRMWARE

Model: C25 Switch Version: 12.0.0

Update content: fixing the problem that method 2 of first connection is not working after version 12.0.0 (see below)

(2) Connect to use

① First connection

Method 1: Install the two Joy-Pad on the rails on both sides of the host screen respectively. Slide the Joy-Pad up and down until it clicks. The host will have an icon to indicate that the connection is successful. After a successful connection, you can detach the Joy-Pad to use, and the Joy-Pad will automatically connect to the host. Note: A host can connect up to 6 control devices, and a Joy-Pad is equivalent to one control device.

Method 2: 1. Press the host power button to enter the host interface 2. Do the following: "Controllers -" Change Grip / Order ", after accessing this interface, press the SYNC button on both Joy-Pad for more than 2 seconds to connect, at this time, the 4 LEDs will flash like a marquee. Once the connection is successful, the corresponding Player LED indicator is always on. then press the L + R button to use it.

Notices:

1. Please do not update your controller if your controller does not have such a problem.
2. Contact seller if you need anything.

How to update:

1. Download the correct firmware from kinvocatech.com and unzip the file

2. Open below file

3. Turn off controller; holding down 3D joystick, then connect controller to computer

4. Click “update firmware”
5. Success