how to use

CABLE MODE CONNECTION METHOD (USB TO C CABLE)

1. TURN THE MODE CONTROL KNOB TO THE CABLE MODE (RED LED).
2. USE THE USB-C CABLE (USB TO C CABLE) TO CONNECT THE KEYBOARD AND THE DEVICE.
3. USE IT DIRECTLY AFTER THE SETUP IS COMPLETED.

* VERY THAT THE LED STOPS FLASHING AFTER CONNECTION

BLUETOOTH CONNECTION METHOD (CONNECT 3 DEVICES)



(CH1) CONNECT TO THE FIRST BLUETOOTH DEVICE.

1. MODE CHANGE KNOB BLUETOOTH TURN ON CH1 TO INDICATE LIGHT (BLUE LED LIGHT / LINK READY).
2. ENABLE BLUETOOTH ON THE LINKED MACHINE, SELECT THE ACTIONS- MODEL (BT50 OR BT80), AND THE LINK IS SUCCESSFUL.



(CH2) CONNECT TO THE SECOND BLUETOOTH DEVICE.

1. MODE CHANGE KNOB BLUETOOTH TURN ON CH2 TO INDICATE LIGHT (BLUE LED LIGHT / LINK READY).
2. ENABLE BLUETOOTH ON THE LINKED MACHINE, SELECT THE ACTIONS- MODEL (BT50 OR BT80), AND THE LINK IS SUCCESSFUL.

(CH3) CONNECT TO THE THIRD BLUETOOTH DEVICE

1. MODE CHANGE KNOB BLUETOOTH TURN ON CH3 TO INDICATE LIGHT (BLUE LED LIGHT / LINK READY).
2. ENABLE BLUETOOTH ON THE LINKED MACHINE, SELECT THE ACTIONS- MODEL (BT50 OR BT80), AND THE LINK IS SUCCESSFUL.

AFTER THE PAIRING IS COMPLETE, THE CHANNEL CAN BE ALWAYS ON.
[REPAIRING METHOD] PRESS THE FN+Z BUTTON FOR ABOUT 5 SECONDS TO REMATCH ANOTHER DEVICE.
[HOW TO CHANGE BLUETOOTH CHANNEL] TURN THE MODE CONVERSION KNOB TO CHANGE.
[AUTOMATICALLY CONNECT THE DEVICE REGISTERED FOR EACH CHANNEL]

BLUETOOTH CONNECTION METHOD (MAC PC)

1. CLICK SYSTEM PREFERENCES (SYSTEM PREFERENCES) > BLUETOOTH (BLUETOOTH) OF THE COMPUTER.
2. CLICK BLUETOOTH ON.
3. TURN THE MODE CONVERSION KNOB TO SELECT THE BLUETOOTH CHANNEL (CH1 TO 3). (BLUE LIGHT / PAIRING READY).
4. ENABLE BLUETOOTH ON THE LINKED MACHINE, SELECT THE ACTIONS- MODEL (BT50 OR BT80), THE LINK IS SUCCESSFUL.

BLUETOOTH CONNECTION METHOD (WINDOWS10/11)

BEFORE USING THIS PRODUCT, MAKE SURE THAT THE COMPUTER HAS A BUILT-IN OR INSTALLED BLUETOOTH RECEIVER.
* YOU DO NOT HAVE A BLUETOOTH RECEIVER INSTALLED, YOU CANNOT USE.
PLEASE BUY A BLUETOOTH RECEIVER FOR INSTALLATION.

1. THE BLUETOOTH CON APPEARS IN THE WINDOW TASKBAR WHEN YOU CONNECT THE BLUETOOTH RECEIVER TO YOUR COMPUTER.
IF, HOVER OVER THE BLUETOOTH CON AND RIGHT-CLICK
1. CLICK ADD BLUETOOTH DEVICES (ADD BLUETOOTH DEVICE).
4. SELECT THE TYPE OF DEVICE YOU WANT TO ADDED. (ADD A BLUETOOTH).
5. TURN THE MODE CONVERSION KNOB TO SELECT THE BLUETOOTH CHANNEL (CH1 TO 3). (BLUE LIGHT / PAIRING READY).
6. ENABLE BLUETOOTH ON THE LINKED MACHINE, SELECT THE ACTIONS- MODEL (BT50 OR BT80) AND ONE SUCCESSFULLY

INSTALLATION TO ALTERNATE BLUETOOTH PAIRING

PRESSING THE FN+C BUTTON FOR ABOUT 3 SECONDS WILL DELETE ALL DEVICE INFORMATION CONNECTED TO THE CH1/CH2/CH3.

DELETE THE PAIRING RECORD (UNPAIRING) AND DELETE THE DEVICE FROM EACH EXISTING CONNECTED DEVICE.
YOU MUST DELETE THE PAIRING HISTORY INSTEAD OF DISABLING BLUETOOTH.

SYSTEM SWITCHING METHOD

ENTER GRICE WHEN THE KEYBOARD IS CONNECTED TO THE DEVICE
① ANDROID : FN+Q
② WINDOWS:FN+W
③ IOS(IPAD/IPHONE) : FN+E

DEPENDING ON THE MACHINE AND SYSTEM, SOME BUTTONS MAY NOT WORK PROPERLY.
IF THE OPERATING SYSTEM CONNECTED TO THE MACHINE IS DIFFERENT,
CONVERT THE SYSTEM TO YOUR MACHINE OPERATING SYSTEM BEFORE USING IT.

BACKLIGHT SETTING

(1)FN+F1(DECREASE THE BRIGHTNESS) (2)FN+F2(INCREASE THE BRIGHTNESS)
(3)FN+F3(DECREASE THE BRIGHTNESS) (4)FN+F4(INCREASE THE BRIGHTNESS)
(5)FN+F5(SCRN+F5(SLEEP)ON DOWN) (6)FN+F6(SCRN OFF)

HOLD DOWN THE FN BUTTON WHEN USING, AND THEN PRESS THE CORRESPONDING BUTTON.
DEPENDING ON YOUR DEVICE AND SYSTEM, SOME BUTTONS MAY NOT WORK PROPERLY.

CONVERSION METHOD OF KOREAN / ENGLISH

① WINDOWS ANDROID KOREAN / ENGLISH BUTTON
② MAC PC COMMAND+SPACE
③ IOS(IPAD/IPHONE) CTRL+SPACE

SOME BUTTONS MAY NOT WORK PROPERLY, DEPENDING ON THE DEVICE AND SYSTEM

STATUS INDICATOR

① BATTERY INDICATOR (MORE THAN 70% GREEN LEDS) 70% BLUE LED 30% LOWER RED LED CHARGING-GREEN LED FLASHES / BATTER GREEN LED IS ON.
② UPPERCASE LOCK INDICATOR (BLUE LED ON WHEN PRESSING UPPERCASE LOCK BUTTON)
③ DIGITAL LOCK INDICATOR (BLUE LED ON WHEN DIGITAL LOCK BUTTON IS PRESSED)

IOS DEVICE NOTE: THE NUM LOCK FUNCTION IS NOT SUPPORTED AND THE LED IS NOT LIT.
IF THE CAPS LOCK BUTTON IN THE DEVICE SETTINGS MENU ENABLES KOREAN / ENGLISH CONVERSION, THIS FEATURE MUST BE DISABLED FOR CASE TO BE ENABLED AND LED TO BE LIT.
HOW TO DISABLE UPPERCASE LOCKING KOREAN / ENGLISH CONVERSION (WITH KEYBOARD CONNECTION)
SETTINGS >> GENERAL >> KEYBOARD >> HARDWARE KEYBOARD >> DISABLE UPPERCASE LOCKING

18 FUNCTION BUTTONS (12 HOTKEYS)

(F1)FN+F1(DISPLAY SCREEN BRIGHTNESS) (F2)FN+F2(DISPLAY SCREEN BRIGHTNESS) (F3)FN+F3(BASIC/TASKBARING)
(F4)FN+F4(MINIMIZE) (5ALL / WINDOWS) FILE EXPLORER / MAC PROGRAM LIST) (F5)FN+F5(BACKLIGHT REDUCTION)
(F6)FN+F6(BACKLIGHT INCREASE) (F7)FN+F7(PREVIOUS SONG) (F8)FN+F8(PAUSE PLAYBACK / PAUSE)
(F9)FN+F9(NEXT SONG) (F10)FN+F10(MEMO) (F11)FN+F11(DOCUMENT) (F12)FN+F12(CALCULATOR)
(Ins)FN+INS(PERSONALSCAN SPEED REDUCTION) (Hm)FN+HOME(PERSONALSCAN SPEED INCREASE)
(P)FN+P(IOS: BACKLIGHT MODE CHANGE 20%)(Pn)FN+DELETE(ACTIONS INITIALIZATION)
(Ins)FN+INS(IOS BUTTON) (Hm)FN+HOME(TURN OFF BACKLIGHT) * NOT SUPPORTED BY IOS SYSTEM

HOLD DOWN THE FN BUTTON WHEN USING, AND THEN PRESS THE CORRESPONDING BUTTON TO USE.
MAKE A "SYSTEM CONVERSION" ACCORDING TO YOUR OPERATING SYSTEM BEFORE USING IT.
SOME BUTTONS MAY NOT WORK PROPERLY, DEPENDING ON THE DEPENDING DEVICE AND SYSTEM

VOLUME ADJUSTMENT

ADJUST BY TURNING THE VOLUME KNOB

POWER ON / OFF

① TURN ON THE POWER AND SLIDE THE POWER BUTTON TO THE RIGHT TO TURN ON THE POWER.
② TURN OFF THE POWER AND SLIDE THE POWER BUTTON TO THE LEFT TO TURN OFF THE POWER.

CHARGING METHOD

① CONNECT THE INCLUDED USBTOC CABLE TO THE CHARGING PORT.
② CONNECT THE USB PORT PART TO THE CHARGING ADAPTER TO START CHARGING.

FACTORY INITIALIZATION METHODS

PRESS THE FN+ESC BUTTON FOR ABOUT 3 SECONDS
① DELETE THE BACKLIGHT SETTING.
② (DELETE ALL DEVICE INFORMATION CONNECTED TO BLUETOOTH (CH1 TO 3). (INITIALIZE CONNECTING.

BATTERY HIBERNATION MODE

AFTER ABOUT 30 MINUTES OF INACTIVITY, ENTER SLEEP MODE. PRESS ANY BUTTON TO ENTER THE OPERATION MODE AUTOMATICALLY.

MODULE

KEYCAPS + COLOR BUTTON CAP + CABLE + BUTTON CAP INSERTER + USER GUIDE

NOTE

BE SURE TO SHIELD/AVOID TEMPERATURE WITH THE INSTRUCTIONS BEFORE USING THIS PRODUCT.
IF THERE ARE A LOT OF BLUETOOTH DEVICES AROUND, FREQUENCY DISRUPTION MAY OCCUR. AVOID INTERFERENCE BY OTHER BLUETOOTH DEVICES.
IT IS DIFFICULT TO INSTALL THE BATTERY (BATTERY).
PLEASE DO NOT DISASSEMBLE OR WEAKENS AT WILL.
IT IS RECOMMENDED THAT YOU REMOVE THE KEYBOARD AND SETUP WITH THE POWER OFF, AND THEN CLEAN.
WATERPROOF AND DUSTPROOF FUNCTIONS ARE NOT SUPPORTED. AVOID CONTACT WITH WATER OR DUST AND OTHER POLLUTION.
DO NOT DISCONNECT OR ON/OFF THE BLUETOOTH WHEN YOUR DEVICE IS ACTIVE.
FOR THE AUTHORIZED CHARGING CABLE THAT COME WITH THE PRODUCT. 24 HOURS AT THE MOST.
THE CHARGING TIME VARIES DEPENDING ON THE COMPUTER ENVIRONMENT (OUTPUT). IT IS NOT RECOMMENDED TO USE IT WHEN CHARGING.
IF THE BATTERY IS TOO HOT OR TOO COLD, IT MAY SHORTEN THE BATTERY LIFE AND STOP WORKING TEMPORARILY.
DO NOT STORE IT IN A HOT AND HUMID PLACE. IT COULD CAUSE A FAILURE.
BE CAREFUL NOT TO HURT YOUR HAND WHEN OPENING THE PACKAGE. THE PACKIGN COULD GET HURT.
PRODUCT SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

SPECIFICATIONS

PRODUCT NAME AND MODEL	BT50
MANUFACTURING COUNTRY	CHINA
SIZE / COMPONENT	84PCS(KEYCAPS/BT50)
COLOR OPTION	WHITE+IVORY+NAVY BLUE+BLACK
PATTERN	2 BLUETOOTH CHANNELS, NPKEY CAN TO 1 CH2
CABLE LENGTH	1.5M
BLUETOOTH VERSION	BLUETOOTH 5.1
BUTTON LIFE / NUMBER OF BUTTONS	50 MILLION TIMES / 84 DEVICE
BUTTON MODE	MECHANICAL TYPE
WORKING VOLTAGE / WORKING CURRENT	DC5.0V/MA
POWER CONSUMPTION OPERATION MODE	100MA (DEFAULT BACKLIGHT) /STANDBY 10MA SLEEP MODE 8MA
BATTERY CAPACITY	2000MAH/3.7V
BATTERY LIFE	BATTERY LIFE (BACKLIGHT OFF/ FULLY BRIGHT)
	WORKING CONTINUOUSLY FOR 10 HOURS
BATTERY CHARGING VOLTAGE	5V/1A
OS	ANDROID 7.0,IOS 10.4WINDOWS98/10/11(MAC 10.9 ABOVE