



Thank you for choosing Kiwi Master® Mats!

The production of Kiwi Master® mats, made of 100% recyclable TPE that is free of any Cadmium, Lead, Latex or PVCs, is energy-saving and more importantly, generates less wastes in the process, a bonus for environment protection efforts. TPE is known for its superior properties against UV and harsh weather conditions, and it is non-toxic and odourless, and will not emit toxic gases under extremely hot temperatures during summer, providing a safer inner environment for you and your family.

Kiwi Master® mats, laser measured to protect the front, back and even upside of your vehicle's footwell, are engineered for ultimate strength and dependability. High density TPE with advanced surfacing keep mess from your shoes.

Installation Instructions:

1. Remove factory floor mats before installing your Kiwi Master® mats, and it is highly recommended to install your floor mats from the driver's side, to the passenger's side then to the rear if applicable.
2. Move the front seats to their rearmost position, then starting installation.
3. Please ensure that the retention hole engages your existing retention points and that your Kiwi Master® mats are securely fastened to the floor.
4. Please fully step on the accelerator, brake and clutch to ensure there is no interference with Kiwi Master® mats.

Note:

1. You are required to remove any existing floor mats before installing Kiwi Master® mats!
2. The Kiwi Master® mats are precisely engineered to fit only the intended model.
3. Failure to correctly install the Kiwi Master® mats in accordance with the instructions above might result in the loss of control of the vehicle and death or serious injury.

Best Warranty in the Business:

Kiwi Master® warrants that the floor mats will be free from any defects in materials and workmanship for the LIFETIME to the original purchaser and only for the original vehicle on which they were installed. That does not mean natural wear and tear from normal use is a reason for replacement or refund.

Customer satisfaction has always been the motivation behind our progress. We will work to deliver a satisfactory answer to your problem and will either replace your mat at no charge or charge you a prorated amount for a replacement, which means we may extend a discount to you to purchase an exact replacement, and proof of purchase is required.

Exclusions to the Warranty include wear due to severe abrasive conditions, chemical contamination, including spilled gasoline, bleach, vehicle accidents, misuse, abusive use, incorrect installation and use, etc.

Please note that chemicals below will cause TPE or Rubber to turn brittle:

- Acetic Acid Aq.
- Acetone
- Ammonium Carbonate Aq.
- Ammonium Chloride Aq.
- Benzene
- Calcium Hypochlorite
- Chloroform
- Chromic Acid Aq.
- Ethyl Acetate
- Ethylene Glycol Aq.
- Formaldehyde Aq.
- Citric Acid
- Heptane
- Hydrofluoric Acid Aq.
- Lubricating Oils (Petroleum)
- Methyl Ethyl Ketone
- Methyl Chloride
- Mineral Oils
- Oleic Acid
- Ozone
- Phosphoric Acid Aq.
- Toluene
- Turpentine
- Zinc Chloride Aq.

Some of these chemicals can be found in the cleaning solutions for heavy machinery. Products like Rain-X for glass contains many of the prohibited chemicals. It is highly recommended not to use any products containing these chemicals, since any damages caused by them will not be covered.