



SPEAR RUNNING BOARD

PART #: TAC-NA6-018

FITS: 2005-Up Nissan Frontier Crew Cab



60-120 min



Cutting Not Required



Drilling Not Required


Torque & Tools

Fastener Size	Tightening Torque (ft-lbs)	Wrench Required		Allen Wrench Required	
					
<input checked="" type="checkbox"/> 6mm	<input checked="" type="checkbox"/> 7-8.5		<input checked="" type="checkbox"/> 10mm		<input type="checkbox"/> 4mm
<input checked="" type="checkbox"/> 8mm	<input checked="" type="checkbox"/> 18-20		<input checked="" type="checkbox"/> 13mm		<input type="checkbox"/> 5mm
<input type="checkbox"/> 10mm	<input type="checkbox"/> 35-40		<input type="checkbox"/> 16mm		<input type="checkbox"/> 6mm
<input type="checkbox"/> 12mm	<input type="checkbox"/> 60-70		<input type="checkbox"/> 18mm		<input type="checkbox"/> 8mm

BEFORE INSTALLATION

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.


Part List





x12

8mm Flat Washer



x12

8mm Flange Nut



x12

6mm x 20mm T-Bolt



x12

6mm x 22mm Flat Washer



x12

6mm Lock Washer



x12


6mm Hex Nut

PLEASE NOTE THAT THE FOLLOWING PICTURES ARE BASED ON THE PASSENGER SIDE INSTALLATION

STEP 1

Starting from underneath the Passenger/Right body panel. Locate the front factory mounting location along the inner side of the body, **(Fig 1)**. Use a wire brush or thread chaser die to remove excess paint and/or undercoating from two studs.

FIG 1




(Fig 1) Passenger/Right front mounting location

STEP 2

Select the (1) Mounting Bracket. Attach the Bracket to the front location with (2) 8mm Flat Washers and (2) 8mm Flange Nuts, **(Fig 2)**. Do not tighten hardware.

FIG 2



(Fig 2) Attach (1) Mounting Bracket to the front location

STEP 3


Repeat **Steps 2** to attach the remaining (2) Mounting Brackets to the center and rear locations, **(Figs 3-4)**. Do not tighten hardware.

FIG 3




(Fig 3) Passenger/Right center mounting location

FIG 4



(Fig 4) Passenger/Right rear mounting location

FIG 6




(Fig 6) Attach (1) Running Board to the Mounting Brackets

STEP 4

Select (1) Running Board. Insert (6) 6mm T-Bolts into the channels in the bottom of the Running Board, (Fig 5), (3 T-Bolts per channel). Attach the Running Board to the (3) Mounting Brackets with (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, (Fig 6). Do not tighten hardware.

FIG 5



(Fig 5) Insert (6) 6mm T-Bolts into the channels in the bottom of the Running Board, (3 T-Bolts per channel)

STEP 5

Level and adjust the Running Board and fully tighten all hardware.

STEP 6

Repeat **Steps 1—5** to attach the other side Running Board.

STEP 7

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Attention

To protect your investment, do not use any type of polish or wax that may contain abrasives that could damage the finish.

Mild soap may be used also to clean the Running Boards.