

# LEVELING LIFT KITS

## 2016+ Can-Am Defender leveling lift kits installation instructions



### BILL OF MATERIALS

Description

QTY

Cam-Am Defender 2" Lift Bracket

4

M10x1.5x60 mm Bolt

8

M10 Lock Nut

8

Shock Spacer

8

1. Raise machine off ground, secure on jack stands, and remove Wheels, Front Box, and Rack if applicable.

2. Remove lower Shocks .



3. Install the new Brackets with the new bolts. Pay attention to the

direction of bracket slope.



4. Install the Shocks into the new Brackets. The Shock Spacer mounts on the inside of the Brackets.



5.Repeat steps for other shocks. Tighten all hardware completely and reinstall Wheels.



**We suggest re-tightening all bolts and nuts on the lift kits after driving 100-200 miles .**

## **Thank you for the purchases!**

It is our honor to help you. So please write us about what you think and what you need.

We will reply you ASAP and try our overwhelming best to help you solve the problem.

Please feel free to contact us via eBay message or Amazon tools.

Amazon:

1. Visit [www.amazon.com/your-orders](http://www.amazon.com/your-orders)
2. Find your product
3. Click on “contact seller”
4. Include your order #

eBay:

1. Visit [www.ebay.com](http://www.ebay.com)
2. Click on ”My eBay”
3. Find your product
4. Click on “More actions”
5. Click on “Contact seller”