

Upper Control arms

Installation Instructions

NO. 293056



This control arms # 293056 fit the following vehicle,

GMC Sierra 2500HD 3500HD 2011+
Chevy Silverado 2500HD 3500HD 2011+

1. Use a floor jack to raise the front of the vehicle, and place jack stands under the frame. Finish removing the lug nuts and wheel.
2. Remove front shock absorbers.



3. Disconnect ABS and brake line mounting brackets from Upper Control Arms and spindles.



4. Mark the control arm position. Before loosening any of nuts, you need to mark off the control arm's position.



5. Loosen the upper ball joint nuts until there is a visible gap between the nut and spindle.



6. Using a hammer, hit the side of the knuckle attached to the upper control arm's ball joint. Continue hitting the knuckle until the ball joint has been freed.



7. Loosen the control arm nuts on both sides.



8. Remove old Control arms and then install new control arms. Adjust the control arm alignment to the marked area. Mount the control arm ball joint to the hub assembly.



9. Reinstall all others.

10. Alignment recommended after installation !

1: the parts packaged in opp bags as shown

2: contact us for video if can't assemble these parts
(an easy work)

3: Important Tips on zerks

No. 1 & No. 2 zerks can inject grease after some use (pre-greased when you get it)

No.3 zerk (under the cover) just a decoration, sealed and pre-greased, so

Do not try to inject anymore, or you will damage it

4: Do not torque the zerk too tight and It can turns to different directions(not must vertical)

---the right and left zerks no need to the same directions

5: Warranty of the ball joints and bushings

We support a one-time free exchange within 1 year if broken

6:contact us if meet any issues before a misunderstanding comment~

