

Upper Control Arms (C293062)

Installation Instructions



This control arms # 293062 fit the following vehicle
2001-2010 Chevrolet Silverado 2500HD/3500HD
2001-2010 Sierra 2500HD/3500HD

1. Use a floor jack to raise the front of the vehicle, and place jack stands under the frame. Finish removing the lug nuts and wheel.

2. Disconnect ABS and brake line mounting brackets from Upper Control Arms and spindles.



3. Mark the control arm position. Before loosening any of nuts, you need to mark off the control arm's position.



4. Loosen the upper ball joint nuts until there is a visible gap between the nut and spindle.

5. Using a hammer, hit the side of the knuckle attached to the upper control arm's ball joint. Continue hitting the knuckle until the ball joint has been freed.



6. Loosen the control arm nuts on both sides.



control arm ball joint to the hub assembly.



7.Remove old Control arms and then install new control arms. Adjust the control arm alignment to the marked area. Mount the

8.Reinstall all others.

9.We recommend that align after installing.

Warranty of the ball joints and bushings

We support once chance to exchange parts for free within 1 year if the control arms go wrong.

If you have any questions ,be feel free to contact us.

Thank you for the purchases!

It is our honor to help you.

It is our honor to help you. So please write us about what you think and what you need.

We will reply you ASAP and try our best to help you solve the problem.

Please feel free to contact us via eBay message or Amazon tools.

E-mail: speed@nbgoldenlion.com

Amazon

1. Visit www.amazon.com/your-orders
2. Find your product
3. Click on “contact seller”
4. Include your order #

eBay

1. Visit www.ebay.com
2. Click on “My eBay”
3. Find your product
4. Click on “More actions”
5. Click on “Contact seller”