

# Quick Installation Guide

## wall mount with screws

### WARM REMINDER

- \* For installation on ceramic tiles, recommend to use 3M tapes.
- \* To wall mount on ceramic tiles with screws, must use proper drilling tools to avoid cracks.
- \* Manufacturer does not assume any responsibilities for tile cracks.



At 20 in. (50cm) above the sink, use the wall mount plate to mark screw positions and drill holes.



Insert the expandable screw caps into the holes for a tight fit.



Position the wall mount plate accurately and tighten the screws.



Insert adaptor jack-plug into the back side and push cable into the recessed channel.



Properly hang the main control unit on to the wall mount plate.



Press in electrolysis generator jack-plug on to the left side.

*Finally, plug the power adaptor into the wall and you are ready to start sterilizing your favorite food ingredients!*

# Quick Installation Guide

## wall mount with 3M tapes

### WARM REMINDER

- \* Allow 12 hours for 3M tapes to firm up for secure positioning before hanging on the main control unit.
- \* If the wall is painted, or other than ceramic tiles, recommend to wall mount with screws.



At 20 in. (50cm) above the sink, wipe clean free of any oil or dust particles, await surface to dry.



Peel off one side surface layer of 3M tapes and stick on to the wall mount plate.



Peel off both remaining tape layers from the wall mount plate and adhere to the wall.



Insert adaptor jack-plug into the back side and push cable into the recessed channel.



Properly hang the main control unit on to the wall mount plate.



Press in electrolysis generator jack-plug on to the left side.

*Finally, plug the power adaptor into the wall and you are ready to start sterilizing your favorite food ingredients!*