



# **User's Manual**

### **INSTALLATION INSTRUCTIONS**

## **Installation Manual**





## **RB001G**

IAPMO RESEARCH AND TESTING, INC.






#### **BEFORE INSTALLATION**

This product has been inspected and debugged by the factory to the best condition. Please do not disassemble it vourself.




Before installing the product, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the product.






- (1) Basic Drain Trough
- (2) Grating (tiled)
- (3) Strainer
- (4) Elastic sealant Silicone
- (5) Tiles
- (6) Thin set tile adhesive
- (7) Grout
- (8) Pre-assembled waterproofing membrane
- (9) Thin-set sheet membrane (entire floor!)
- (10) Sloped mortar bed first layer
- (1) Sloped mortar bed second layer
- (12) Pan liner / Moisture resistant material
- (13) Pea Gravel
- (14) 2"Clamping drain base
- (15) 2"Clamping ring
- (6) 2"Sealing rubber ring
- (17) Sealant between membrane & mortar
- (18) Drainage pipe




#### **INSTALLATION STEPS**




1. Install the clamp drain base to ensure that the drain port of the base is connected to the drain pipe tightly.




2. Sloped mortar bed, ensure that 3. Adjust and fix in place. the clamp drain base is installed and consistent.







4. Put sealant around.




5. Cover the mortar bed with a waterproof membrane.




6. Cover the entire floor with waterproof membrane.




7A. Plus cement retaining plate.




7B. Or choose a shower with a hood.




8. Screw 4 fixing screws on the base.



9. Add sealing rubber ring.




10. Put the clamping ring into the screw, turn and lock.




11. Slash the waterproof membrane with a knife at the drain.



12. Fit the plastic coupler.




13. Tighten it to the right position.




14. Put the floor drain into the clamp drain base and adjust it with a spirit level.


#### **INSTALLATION STEPS**




15. Test water tightness




16. Cement.




17. Leave a slope of not less than 2 degrees on the ground against the floor drain.




18. Sloped mortar bed




19. Cover the mortar bed with a waterproof membrane.




20. Apply tile adhesive.




21. Install tiles.




22. Put on the sealant.



23. Cover the surface with tiles and install it to the main body of the floor drain.





#### **CLEANING CARE**

In order to keep the appearance of product clean, bright and good performance, please take care of the product as follows;

- 1. Rinse with water only and dry with soff cotton cloth;
- 2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect;
- 3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc;
- 4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc;
- 5.In the process of use, mud my accumulate in the bubbler and make the water flow show,
- The bubbler can be unscrewed, rinsed with water, and then installed back in place.

Please feel free to contact us if you have any questions. We will help to solve the issue together with you. OUR EMAIL: services@rbrohant.com





Service Contact:

+1(801) 800-9309 services@rbrohant.com

Made in China