

# 10294 Titanic P29102

- P29102 is the unique code of lighting set, we use this to accurately identify the product you purchased and the corresponding manuals and services you need to obtain. Please make sure your product code is the same as the label on the back of the box shown “10294 P29102”.
- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



# Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

## **Section A:** Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

## **Section B:** Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

## **Section C:** laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation steps.

## **Section A: Check the type and quantity of components.**

There are 14 bags in this set. The name and quantities of specific components are as shown , please check carefully.

<b>Label</b>	<b>Content</b>	<b>Quantity</b>
<b>Light Strips-Warm White-21</b>	<b>Light Strips-Warm White-21</b>	<b>5</b>
<b>Light Strips-Warm White-28</b>	<b>Light Strips-Warm White-28</b>	<b>17</b>
<b>Light Strips-Warm White-7</b>	<b>Light Strips-Warm White-7</b>	<b>2</b>
<b>Bit Lights-30CM-Warm White</b>	<b>Bit Lights-30CM-Warm White</b>	<b>31</b>
<b>Headlights-15CM-Warm White</b>	<b>Headlights-15CM-Warm White</b>	<b>3</b>
<b>Light Strips-Cyan -28</b>	<b>Light Strips-Cyan -28</b>	<b>5</b>
<b>Bit Lights-30CM-White</b>	<b>Bit Lights-30CM-White</b>	<b>4</b>
<b>USB Power Cable</b>	<b>USB Power Cable-30CM</b>	<b>2</b>
<b>Connecting Cables-30CM</b>	<b>Connecting Cables-30CM</b>	<b>3</b>
<b>Connecting Cables-20CM</b>	<b>Connecting Cables-20CM</b>	<b>5</b>
<b>Connecting Cables-50CM</b>	<b>Connecting Cables-50CM</b>	<b>14</b>
<b>Expansion Board</b>	<b>2 Socket Expansion Board</b>	<b>6</b>
	<b>4 Socket Expansion Board</b>	<b>11</b>
	<b>6 Socket Expansion Board</b>	<b>5</b>
	<b>8 Socket Expansion Board</b>	<b>3</b>
	<b>12 Socket Expansion Board</b>	<b>3</b>
<b>Spray Module</b>	<b>Spray Module</b>	<b>4</b>
	<b>Parts package</b>	

Please contact us immediately if there have any missing components.


## Section B: Test that each components is working properly.

We need a structure to test all lights, so take out the bag with label “USB Power Cord”and “Expansion Boards”as follows.




It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.

Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needle in socket of the expansion board. shown as blow.




All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the USB Power Cord and Expansion Boards is as follows:




The USB Power Cord can be powered by phone chargers, power banks, etc.



**This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.**



**when we test "Headlights-15CM-Warm White" particles,Take out the bag labelled "Headlights-15CM-Warm White".Take out one of the light and connect it to the socket. Turn on the power bank, the light will turn on normally as shown below.**



**Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.**




**The components needs to be tested in this set is 5\*Light Strips-Warm White-21, 17\*Light Strips-Warm White-28, 2\*Light Strips-Warm White-7, 31\*Bit Lights-30CM-Warm White, 3\*Headlights-15CM-Warm White, 5\*Light Strips-Cyan -28, 4\*Bit Lights-30CM-White.**



**Please contact us immediately if any components don't work.**

## Section C: laying out components following the instruction.



1




2




3




4




5



6




7



8




9








13



14




15




16





17





18



19





20





21





22




23




24




25




26



27




28



29





30




31



32



33




Take out Light Strips-Warm White-21 lights.





34




35





36





37




38





39





40




41




42




43



44





45



Take out Light Strips-Warm White-21 lights.




46




47




48



49




50




Take out Light Strips-Warm White-21 lights.





51





52





53




54




55




56



57




58



59




60



Take out Light Strips-Warm White-21 lights.



61





62





63



64




65





66




67





68




69



70




71





72




73




74




75





76




77





78




Take out Light Strips-Warm White-21 lights.



79





80





81




82





83




84





85




86



87





88





89





90





91




92





93




94





95




96




97




98





99




100





101





102




103



104




105





106




107



108





109




110





Fix the lamp pellet at the position selected by the frame in the figure, with the solder joints of the spray module components facing upwards.



111





112




113





114




115





116





117





**Pull the connecting line on the expansion board to the right, and place the connecting line between the bumps of the blocks.**




**118**




**Pull the spray module line at the bottom to the top.**




119





120





121





122





123





124



125



126




127





128





129





130



131




132




133




134



135



136





137



138





139




140




141



142




143




144




145




146




147




148





149




150




151




152





153




154




155



156





157




158



159



160



161




162




163





164




165





166




167




168




169





170





171





172



173




174





175





176




177



178





179




180





181




182



183




184




185




186



187




188




189




190




191



192





193





194



195



Remove the 50 cm cable from the 12 expansion board and replace it with a 20 cm cable.




196




197



198





199



200





201





202



203





204



205




206




207




208





209





210




211





212





213




214




215



216




217





218





219





220



221





222





223




224




225





226




227



228





229




230




231





232



233



234




235




236




Fix the lamp pellet to the position selected in the figure, with the solder joints of the spray module components facing upwards.





237




238




239




240




241




242



243





244




245





246





247




248





249




250





251



252




253



254




255





256




257





258





259



260




261



262




263





264



265




266




267





268




269





270




271





272




273




274




275





276





277





278





279



280





281




282




283



284




285





286




287



288





289







293





294




295




296




297




298




299





300




301



302



303



304



305





306




307




308





309




310




311




312





313





314




315




316





317





318




319




320



321





322




323



324




325





326




327





328





329




330



331



332





333





334




335



336




337




338




339





340



341




342





343



344




345




346




347




348





349





350





351





352





353





354




355





356





357




358





359





360





361





362





363



364




365



366



367




368





369



Fix the lamp pellet to the position selected in the figure, with the solder joints of the spray module components facing upwards.




370



371





372





373



374





375





376




377




378





379




380




381




382




383




384





385



386




387



388



389



After restoring as shown in the figure, place the packing box in the middle of the hull.



Place the model diagonally against the mounting box.



390



391




392





393




394




395




396




397



398



399




400




401



402



403



## 404



## 405





## 406




407



408



Place the connecting line in the picture in the gap between the blocks and pull the connecting line to the top.



409



410




**Connect the cable to the expansion board.**





Take out the previously tested mobile power supply and USB power cord and an 8-seater expansion board.



Find out the connection line of the ship's headlights.




Connect the ship's headlight cable to the power source and see if the ship's headlight is lit.





Then take off the ship's headlight cable and connect it to the 4-seater expansion board just taken out.





Find the connection line of the stern light.




Connect the stern light cable to the power supply and see if the stern light is lit.




**Take off the stern light cable and connect it to the 4-seater expansion board.**




**Find the connection line of the atmosphere light at the bottom of the hull.**




**Connect the ambient light at the bottom of the hull to the power source and see if the stern light is lit.**




**Then remove the connecting wire of the atmosphere light at the bottom of the hull and connect it to the four expansion board.**




**Find the connection line of the lights on the first floor of the hull.**



**Connect the connecting line of the light on the first floor of the hull to the power source and see if the light on the first floor of the hull is lit.**





**Find another connection line for the lights on the first floor of the hull.**





**Connect the connecting line of the light on the first floor of the hull to the power source and see if the light on the first floor of the hull is lit.**




**Then thread the found thread into the hull.**




**Pull it to the left, and then connect it to the expansion board.**



**Unplug the 20cm cable on the 12 expansion board from the power supply and place it at the position shown in the figure.**




**Locate the light connection line on the second floor of the hull.**




**Connect the connecting line of the lamp on the second floor of the hull to the power source and see if the lamp on the second floor of the hull is lit.**




**Find another second floor lamp connection line.**





**Connect the connecting line of the lamp on the second floor of the hull to the power source and see if the lamp on the second floor of the hull is lit.**





**Take off the connection line of the lamp on the second floor of the hull from the power supply.**




Pass the connecting line of the lamp on the second floor of the hull through the building block at the bottom and pull it to the left.




Connect the cable just pulled over to the 8-seat expansion board in the picture.




**Unplug the 20cm cable on the 8-seater expansion board from the power supply.**




**Then place it in the position in the picture.**




**Find out the connecting wire of the deck light.**




**Connect the deck light cable to the power source and see if the lights on the deck are lit.**



**Find the connection line of another deck light.**





**Connect the power supply to see if it is lit.**




**After confirmation, remove the deck light cable from the power supply.**



**Pass the deck light connection line through the bottom block part and pull it to the left.**




**Connect the connecting wires that pass through to the 12 expansion boards in the picture.**





**Then unplug the 20cm cable on the 12 expansion board from the power supply.**





**Place it in the position in the figure.**



411




412




413





414




415




416




417





418





419




420




421



422



423




424



Fix the lamp pellet at the position selected by the frame in the figure, with the solder joints of the spray module components facing upwards.





425



426




427




428





429




430




431





432




433



434




435




436




437




438



439




440





441





442



443



444



445




The position selected by the frame in the figure is the switch of the spray module (after the module is powered on, press the switch to use).





446




447



448



449




450




451



452




453



454



455




456





457



458



459




460





461





462




463




464




465



466





467



468





469



470



471




472



473




474




475



476





477




478



479



480



481




482



Press the dropper, and use the dropper to pour water into the cotton ball (the other three places are also operated in the same way).



**Because there are many lights, it is recommended to use plug-in power supply directly.**



**Good job, you've done all the installation steps, power it up and enjoy your work.**



**If everything is as excellent as expected, we'll be appreciate if a good review can be given.**

**THANKS**