



TURN ALL POWER OFF BEFORE STARTING INSTALLATION.

Route Blue, Black and Yellow SoftStart wires into the electrical box. Then crimp Connectors onto all SoftStart wires as indicated in drawing.

- Step ① Follow White Compressor Wire from Compressor to Run Capacitor "C" terminal. Disconnect from "C" terminal and connect it to Blue SoftStart wire.
 - Step ② Connect Black SoftStart wire to the terminal that the White Compressor Wire was on.
 - Step ③ Connect Yellow SoftStart wire on a terminal next to Red Compressor Wire on "Herm" Side of Run Capacitor.
 - Step ④ **IF you see a second Red wire** next to the Red Compressor Wire, disconnect it and seal end with electrical tape.
 - Step ⑤ Remove Compressor cap. Disconnect Blue Compressor Wire and connect to Red SoftStart wire. Tape connection.
- NOTE: Do not place wires back under the Compressor cap.**
- Step ⑥ Crimp Female flag on end of Brown SoftStart wire. Connect Brown SoftStart wire on the Compressor terminal that the Blue wire was on. Route wire to exit cap with White and Red wires. Replace cap.

Secure all wires. Tape connections with electrical tape.

Turn Power and A/C Breaker on. Turn A/C to Auto Cool setting and the thermostat to 55°F.

Look at SoftStart LED lights. Green light should be "On" (green light means the Compressor is running).

Green light should turn "Off" during shut down. Re-install all A/C covers. Turn A/C back on and run for 30 minutes.

IF there is no Green light, call SoftStart Tech Support for assistance.

Wiring Diagram for Advent Air Flag NC