



INSTALLATION INSTRUCTION

1. Punch a hole in the cabinet door, the pitch of the hole pls refer to the image.
2. Install the base: Fix the base to the cabinet with a screwdriver (Note: Hydraulic hinge that can be separated has a button at the bottom of the hinge, click on it and the base will be released)
3. Align the hinge with the hole and fix it with screws
4. Install the fixed hinge align to the base, then press the bottom of the hinge to install it.
5. Adjust the central screw and make sure the door in place

TamBee

