

## **INSTRUCTIONS:**

1. To remove old shower arm and flange place strap wrench around arm and turn counter-clockwise.

Pull old flange off.

2. Apply pipe joint compound or joint to new shower arm threads. Push new flange on and thread into fitting in ceiling. Turn arm clockwise until straight and tight.

## **INSTRUCCIONES:**

1. Para sacar el brazo existente de la ducha tomarlo con una llave para tubos y hacerlo girar en sentido antihorario. Sacar la brida existente.

2. Aplicar sellante de rosca o cinta de Maincraft en los filetes de la rosca del brazo nuevo. Empuje la nueva brida y enhebrar en el accesorio en el techo.

Gire

el brazo en sentido de las manecillas de reloj hasta que esté derecho y ajustado.

