Thanks for choosing smart ambient light. With this Wi-Fi smart light you can change light style using your phone anytime from anywhere and let the light work for you, enjoy your life.

Product Illustration



Button — Press the switch button 5 times to enter the network configuration mode

(1)Power on
(2)Turn On-off-on-off-on Ensure light is fast blinking (switch interval not more than 5 seconds)

Power Socket — Plug in the power cord to charge the light.

Low Battery Indication:

When the Ambient light turns to red and flash 4 times, it indicates insufficient battery power, and begin to power off in 10minutes.

Power Supply:

The built-in 800mAh/3.7V rechargeable lithium battery can provide 3-10 hours of battery life (depending on the brightness and environment).

Technical Specifications:

Input: DC5V 1A
Rated power: 3W
Wireless Type: Wi-Fi 2.4GHz
Operating temperature: 0 ℃ - 40 ℃
Protection Class:IP44
Support system: Android and iOS

Notice:

If you failed to connect network, please try the AP mode to connect network.
(1)Press the switch button 5 times until the light flashes white.(Pairing mode)
(2)Then press the button 6 times during the white flash to enter the slow flash mode.turns cyan and slow flash. (AP mode)
(3) Enter the AP mode in the APP, and then input the Wi-Fi router password.
(4) Connect your cellphone to WLAN “Smart Life_XXXX ” hotspot, and then go back to the APP, tap connection button to finish configuration.
(5) When this ambient light is out of Wi-Fi range, it will disconnect and turn to off-line mode. You need to power off and on with bottom button, or connect power socket to get it back to on-line mode.

Connection Instruction

1. Download the App

Please download “PlusMinus” from App Store, Google Play or our website (www.plusmunis.ai/app). You can also scan the QR below to download the App.

2. Register & Login your PlusMinus account

Fill in necessary information to have access to your account.

3. Add the device

1. Reset the light by turn on/off the switch button for 5 times until lights are fast blinking.
2. Open the App and click “Add Device” at upper right corner and choose the type “Lighting”;
3. Make sure your phone is connected with 2.4Ghz WiFi and fill in the password; click “NEXT”, pairing process gets start.


12:33
Party
All devices
Rooms
Automation
Add Device
Home
Help
Store
Me
12:34
Select Device
Wi-Fi
Lighting
Smart Plug
Smart Switch
Light Strip
Smart Camera
4:25
2.4Ghz
5Ghz
Wi-Fi:chenying
Change Network
Enter wifi password
I am sure my wifi is 2.4GHz Wi-Fi network
NEXT
12:34
2%
Connecting...
Please keep the Wi-Fi router, your phone and the smart device close to each other.

How to connect to Alexa

1.Add devices in “PlusMinus” app;

2.Launch “Amazon Alexa” choose “Skills” from menu;





3.Search “PlusMinus” skill and click “ENABLE”;

4. Enter your “PlusMinus” Account and Password, then click “Link Now”;

5. Control devices by voice.
“Alexa, turn off the light.”
“Alexa, turn on the living room lights.”

How to connect to Google Home

1. Add devices in "PlusMinus" app;

2. Launch “Google Home” and click the “Add” and then “set up device”





3. Click “Have something already set up?” and find "PlusMinus" in the list, enter your "PlusMinus"Account and Password, then click "Link Now";





4. Control your smart devices through Google Home.

Customer service and FAQ

If you have any more questions contact us inside the PlusMinus App



Troubleshooting Frequently Asked Questions

1.Failed to connect device, what should I do?
Double check that phone is connected to a 2.4GHz Wi-Fi band. Confirm the entered Wi-Fi password is correct. And the device is in setup mode(indicator light blinking).

2.How to connect to 2.4GHz Wi-Fi ?
Most smart home devices only support 2.4 GHz Wi-Fi band. Usually the 5 GHz Wi-Fi band has '5'or '5G' in its name, do not connect to that one. You can also log into your Wi-Fi router's admin page on web browser to turn off 5 GHz Wi-Fi. Or please find another phone device. Turn off your current Wi-Fi router, then use the phone as a Wi-Fi hotspot, set the hotspot name and password exactly the same as your main Wi-Fi router. Keep both phones and your smart device close together.

After it is connected, turn off your hotspot and turn on your main Wi-Fi router, the smart device will connect to the Wi-Fi router, as they are the same name and password.

3.The Smart Wi-Fi device appears offline, what should I do?

Check the electric power and make sure that it’s power on. Make sure you are connected to the same Wi-Fi network to control it locally. Reset the Smart device and reconnect it to your Wi-Fi network.

4.How do I pair the Smart Wi-Fi LED light strips with Amazon Echo?

For pairing instructions, please register account and follow the installation steps inside app.

For tutorial video, please search “LUMIMAN Light Bar” on YouTube. The friendly and professional support team are at your service 24/7; Products are with our worry-free 12 month warranty.
Website: www.lumiman.com

Tech Support Email:

support@lumiman.com