



















CONTENTS
English 01-09
Deutsch 10-18
日本語 19-27



System Requirements
Windows: Vista, 7/8/8.1/10 and later...
Features
Professional sound chipset...
How to operation
1. Plug the Microphone into your Computer USB port.



Systemvoraussetzungen
Windows: Vista, 7/8/8.1/10 und neuere Version...
Eigenschaften
Professioneller Soundprozessor-Chipset...
Wie zu bedienen
1. Stecken Sie den USB-Stecker in den USB-Anschluss des Computers



対応システム
Windows: Vista, 7/8/8.1/10 and later...
特長
最高96kHz/24bitサンプリングレートを誇るプロテクションプロセッサ...
接続方法
各製品はパソコンのUSBポートに接続してください。

