XLR10_XLR20 说明书，成品尺寸W55*H90，V2.0_201904017版
双面对折

maono

XLR LAVALIER MICROPHONE

Scan the QR code for more support.

USER GUIDE

V2.0_201904

LXR LAVALIER MICROPHONE

AU-XLR10

1. Microphone
2. Cable
3. XLR connector
4. Clip of microphone

AU-XLR20

1. Microphone
2. Power module
3. Cable
4. XLR connector
5. Clip of microphone

LXR LAVALIER MICROPHONE

AU-XLR10

How to use?

(Firstly, please refer the manual of your device about how to connect XLR microphone to device)

1. Connect MAONO XLR lavalier Microphone to Audio device (camcorder, Audio recorder, Audio Mixer), and turn on the mic power option to +48V power source.
2. Switch to the button of mic selection to EXT of Audio device.
3. Clip the mic on the collar or anywhere close to your mouth.
4. Ready for working.

LXR LAVALIER MICROPHONE

MAONO **AU-XLR20** has battery power module, can be work on phantom power support or battery power support. Please identify is your record device has 48V phantom power supply function or not for XLR microphone before the using.

1. If your record device has 48V phantom power, please turn off the power module switch to "OFF", the microphone will drive by phantom power of record device.

  a) Connect MAONO AU-XLR20 lavalier microphone to record device and turn on the device mic power to +48V power source option.

  b) Switch to the mic selection button of record device to "EXTRA" or "INPUT" options.

  c) Clip the mic to somewhere close to the voice resource, and ready to work.

2. If your record device without 48V phantom power supply, please turn on the power module switch to "ON". The microphone will be drive by battery.

  a) Connect AU-XLR20 to record device.

  b) May you need switch to the mic selection button of record device to "EXTRA" or "INPUT" options

  c) Clip the mic to somewhere close to the voice resource, and ready to work.