

KINVOCA EG13A controller update firmware to play NS Sports games


How to update:

1. Download the correct firmware from kinvocatech.com and unzip the file.


Download link: <https://kinvocatech.com/blogs/manual/files-for-update>



2. Open below file



3. Turn off controller; holding down 3D joystick, then connect controller to computer.
4. Click "update firmware".
5. Success.



Notice:

1. Please don't update your controller if your controller does not have such a problem.
2. Contact seller if you need anything.