





G.最後一步:將藍牙模块插入插槽。 **H.**完成。





HOW TO CHARGE

























When the headphone is turned on and not connected with any device, presthe MF button and Volume Up button simultaneously for 3 seconds, the LED Indicator Light will flash in blue and red at the same time to indicate that the factory reset is successful.

When the battery is low, you will see the red LED indicator flashes twice

1.Plug the USB charging cable into the charging port of the headphone.

• For your first use, please make sure to fully charge the SERENITY beforeha

• You should recharge SERENITY if it hasn't been used for more than 12

2. When the charging begins, the LED indicator light will be red.

3.The LED light turns off when the headphone is fully charged.

4.It only takes around 2 hrs to fully charge the headphone.

GUARANTEE Jabees is a registered trademark of FreeTek International Co, Ltd. Other brands and product names are trademarks of their respective owners. Jabees warrants this product against all defects in material and workmanshi for a period of twelve (12) months from the date of original purchase of the

Keep out of the reach of children. The bags themselves or the many small product. The conditions of this guarantee and the extent of responsibility of parts they contain may cause choking if ingested. Jabees under this guarantee can be read in the Warranty Card. 3. Never attempt to disassemble the product yourself, or push other objects into this product, as this may cause a short circuit, which could lead to fire or electrical shock.

SAFETY INFORMATION

submerged in a liquid, discontinue use.

REMEMBER:

1. If you have a cardiac pacemaker or other electronic medical equipment,

2. This product contains small parts that may be hazardous to children.

you should consult your physician before using this product.

Permanent hearing loss may result from long-term exposure to sound at

4. None of the components can be replaced or repaired by users. Only an high volumes. Use as low a volume as possible and avoid prolonged use of authorized dealer or service center may open the product. the earphone at excessive levels. Please read the safety guidelines below 5. If any parts of your product require replacement for any reason, prior to using this earphone. including normal wear and tear or breakage, please contact your dealer. 6. If the product overheats, has been dropped or damaged or has been

Prior to using this product follow these steps 1. Before putting on the earphone, turn the volume control to its lowest

2. Put the earphone on, and then slowly adjust the volume control to a

comfortable level.

During the use of this product

1. Keep the volume at the lowest level as possible. 2. If increased volume is necessary, adjust the volume control slowly. 3. If you experience discomfort or ringing in your ears, immediately

discontinue using the earphone. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

Drive safely, avoid distractions and follow local laws.

BTHS200709_V1.0

BTHS200709_V1.0