


# TELEPROMPTER MANUAL

## 1-- PRODUCT LIST



## 2-- Android APP TUTORIAL



Scan the QR code to download the teleprompter app



Install the application


Note:

If you cannot install the APP through the above QR code. Please contact us for help.

①

## 3-- iPhone APP TUTORIAL

Search for "keayi" or "qiyeticiqi" in the Apple Store.



Note:

If you can't install the APP through the above search. Please contact us for help.

## 4-- BLUETOOTH REMOTE CONTROL

OK key controls start and pause

Press (OK key) to control the start and pause when pressing to switch to KEY

When pressing to switch to Game, you can control the speed and page turning by (Joystick)


Joystick to control page turning and speed

Switch on / off (long press for 3 seconds) lights up to indicate power on



- 1.Long press the power button until the red light flashes.
- 2.Turn on and set up a Bluetooth connection Bluetooth remote control when the indicator flashes

②





## 5-- EDIT SCRIPT



- 1.Download the APP, click "New Document"

- 2.Enter the title and content and click save


- 3.Click what has been entered



- 5.Click on the lower right settings to set the menu

6. When your phone font is reversed on the teleprompter click on the lower-right menu to change its direction

- 4.Finish (as shown)



note:

If the script is in the opposite direction on the teleprompter, click the upper right corner, and then click "Use mirror".

③

## 6-- TELEPROMPTER INSTALLATION



1. Mobile phone holder installation



2. Place the light shield on the small back panel




3. Install the video phone (horizontal shot)



4. The phone holder can be changed (vertical shooting)



5. Place the desktop



1. Install the tripod with the quick release plate



2. Install teleprompter



3. Pull out the phone visor



4. Install the visor



5. Install the double L-shaped plate



6. Horizontal shot



7. Vertical shot

④