面

USER INSTRUCTION

MiNi Wifi LED Controller






I .Product Parameter:

Category LED Controller Domination Principle APP WiFi FVTLED Operation Platform Android 7.0 or IOS 12.3 or later Channels Input Voltage GRB/RGBW DC(12-24)V Max Output Power Working Temperature Control Distance -20~+55°C Visible distance 30M Certification CE, RoHS, FCC Net Weight Dimension(L*B*H) 33.5g 53MM*24MM*11MM


50CM*25CM*21CM


Carton Size(L*B*H) II .Wire Connection



The connection between the controller and the power vlagus

Controller and device






corresponds to the black arrow of the device end, otherwise the device will have a short circuit.

Important Notice:

If you need to make DIY modification to the device, please contact our customer service and operate under their guidance.
Precautions: please follow the diagram instrustion when doing DIY modifications.



III. Key Instruction



V. How to connect the controller to Wi-Fi network?

1) Register/Login your FVTLED account.




2) Open your phone Bluetooth, turn on the device.


3) Enter "FVTLED" app, tap "Add Device" or click "+" to add the device. Then select your Wi-Fi network(Only works with 2.4Ghz network), enter the password .



4) The device name can be modified and select the room after successfully connecting to Wi-Fi network.



VI. How to reset the factory setting?



IV. Download FVTLED APP

Download "FVTLED " APP from App store and Google Play Store, or scan the QR code.



Scan the "Instruction" QR code to read the electronic manual



Or enter the APP FAQ to learn more

