






















ASSEMBLY INSTRUCTIONS

A	 x1	I	 x1
B	 x1	J	 x1
C	 x1	K	 x1
D	 x1	L	 x16
E	 x1	M	 x4
F	 x1	N	 x4
G	 x5	O	 x1
H	 x1		



P/N: Z1001021A01/02/04

