IK209 GPS Tracker

User Manual V1.0



Preface

Congratulations on choosing the icar GPS IK209 Asset GPS tracker. This manual shows how to easily program and setup the tracker for best results. Make sure to read this manual carefully before using this product, so as to avoid delays or confusion with it's operation. Please note that specifications and instructions are subject to change without notice to facilitate product improvement. Updates and changes will be integrated into the latest release. The manufacturer assumes no responsibility for any errors or omissions in outdated documents.

1

1. Overview

IK209 is a Asset GPS tracker.

2. Features

- Real-timing tracking
- GPS+WiFi Positioning
- History record check
- Geo-Fence alarm
- Low battery alarm
- Power saving mode
- PC & Mobile App tracking
- Mini Hidden
- IP65 Water resistant
- Remove Alarm
- One way communication

3. Applications

- Luggage tracking
- Container tracking
- Logistics tracking

4. Specifications

ltem	Specifications	
Dimension	115*65*25mm/120*65*35mm/120*65*50mm	
Maialat	175g/250g/365g (2G version)	
Weight	192g/290g/444g (3Gversion)	
Charger	DC 5V/1A	
Backup battery	3.7V 6000mAh/10000mAh/20000mAh	
Power consumption	40mA standby current	
Working temperature	-20°C to 65°C	
Item	Specifications	
Cellular Bands	GSM : 850/900/1800/1900Mhz	
Positioning	GPS, AGPS, LBS	

IK209 User Manual V1.0

Tracking Sensitivity	-162 dBm
Sensor	Accelerometer
LED	RED/GREEN/BLUE
SIM Card interface	Mini SIM
Waterproof	IP67

5. IK209 interface



SIM card slot



Power Button

6. In the box

- 1* IK209 GPS Tracker
- 1* Quick Start Guide
- 1* Screw Driver
- 1* Charge Cable

7. Installation

7.1 SIM Card installation

- Get ready a Mini Sim Card that support GSM&GPRS with 30MB data per month
- Open the top housing
- Insert Sim card to sim card slot correctly
- Devices would turn on autoly (green led will blinking).
- After that the device will be ready.

7.2 **LED Indications**

	Flash	Fix	Off
Green Light	GSM/GPRS conversation start	No GPRS signal	Power off or in sleep mode

IK209 User Manual V1.0

Blue Light	GPS location successful	No GPRS signal	Power off or in sleep mode
Red Light		charging	Full battery or charged full

8. SMS Commands List

Function	Command Format	Reply	for example
APN	apn+123456+space+content	apn ok	apn123456 cmnet
	apnuser+123456+space+content	apnuser ok	
	apnpasswd+123456+space+content	apnpasswd ok	
admin number	admin123456+space+admin phone number	admin ok	admin123456 186******
Domain	SZCS,123456,DOMAIN=a.icargps.net:7700	Domain ok	SZCS,123456,DOMAIN=a.icargp s.net:7700
upload frequency	Upload123456 time(unit/s)	ок	Upload123456 10
Monitor	Monitor123456	monitor OK	Monitor123456
sos	SOS,phone1 number,phone2 number	SOS! S1: S2:	SOS,186*****,189*****
Position	where	Google map Link	where
Restart Devic e	RST	Device would restart i	RST
Check	Param1	details of device	Param1
Status	Status	Status of device	Status
Back to facto	Format	ок	Format

9. App & PC Tracking platform

9.1 App install & Login

 Search "ICAR GPS" in Google Play or iOS store(or scan the following QR code) to download the Mobile APP;



ICAR GPS APP

ICAR GPS AF

- Choose the" Login by Device No.,
- Input your device's ID number and password(default is 123456) to login.






- Choose the" Login by User name.,
- Input your user name and password(default is 123456) to login.

9.2 PC login

- Web: <u>www.i</u>cargps.net, Choose "ID No."
- Input your device's ID number and password(default is 123456) to log in



- Web: www.icargps.net, Choose "Account"
- Input user name and password(default is 123456) to log in



10. FAQ

- Q: Start up Fail?
- A: Check the device power on or not.
- Q: The device can not obtain location information?
- A: Place the unit at the open area to test.
- Q: How to choose SIM card?
- A: the SIM card must support GSM&GPRS, and ensure that the card has enough currency and credit.
- Q: How to use in the foreign countries?
- A: please set the APN before use, please edit the text "A PN123456 CMNET " and send it to the SIM card of the d evice, CMNET is Chinese operator's APN, Replace the corr esponding APN when use in other countries, APN details, please consult your local SIM card carrier.