




NEO  
GRIP

# Instructions


## Fitting the NeoGrip:

1




Remove one of the joy-cons and put the SWITCH into the NeoGrip.

2



Gently insert the joy-con.


3



Slide in the holder.


## Removing the NeoGrip:

1




Remove one of the joy-cons.

2




Slide off the holder.

3




Remove the SWITCH.

## Switching Grips:




Slide grip downwards to remove and upwards to install.



Please ensure the slider is fitted correctly.


## Switching to fit regular SWITCH:

1




Remove the screws.

2



Slide off the spacer.

3



Install the screws.