



USER INSTRUCTIONS



Seat Height

Pull up the paddle to adjust the seat height.




Backrest

Adjust the tilt angle by pulling out the paddle.




USER INSTRUCTIONS



Lumbar Support


Move the lumbar support behind the backrest to adjust the lumbar support position.



Armrest

Press the button under the armrest to adjust the armrest height.

USER INSTRUCTIONS



Headrest

The height of the headrest can be adjusted.