





H10

Hybrid Active
Noise Cancelling Headphone

User Manual



PACKAGE LIST






IMPORTANT NOTES

- 1 Register your headphone at www.tranya.com to get an EXTRA three-month warranty for free.
- 2 Please charge the headphones before use.
- 3 Please contact us at support@tranya.com for any assistance.



POWER ON/OFF



Power On



3" 3x

Press and hold for 3 seconds
Flashing blue 3 times (Status indicator)

Power Off





3" 2x

Press and hold for 3 seconds
Flashing red 2 times (Status indicator)



PAIRING



Enter Bluetooth pairing mode when H10 is off



Press and hold for 5 seconds

Pairing mode




Blue & red light flashes intermittently



ACTIVE NOISE CANCELLATION

Active Noise Cancellation (ANC) mode blocks the surrounding noises while wearing Tranya H10. Ambient mode naturally filters in environmental and ambient noise to help you stay aware of your surroundings.



Press

ANC (active noise cancellation) on

ANC (active noise cancellation) off

Ambient mode




LISTENING TO MUSIC



	Press	Play/Pause
	Press	Volume up
	Press and hold for 1 second	Next track
	Press	Volume down
	Press and hold for 1 second	Previous track
	Press V+ and V- and hold for 1 second	Activate Siri / Google Assistant




CALL OPERATION



x1	Press	Answer / End call
x2"	Press and hold for 2 seconds	Reject call
x2	Double press	Redial last number
	Press V+ and V- at the same time	Mute / Unmute
x3"	Press and hold for 3 seconds	Switch between headphone and your phone



CHARGING YOUR HEADPHONES



You will hear a voice prompt of "DuDu" every 3min when there are only 10min of playtime left.

Low battery



Steady red

Charging




Steady blue

Fully charged



LINE-IN



2.5mm Audio Cable

Plugging in a 2.5mm audio cable will automatically switch to Line-in mode, and you can still operate the ANC functions. If the H10 is off, please power it on to activate the ANC functions.



MULTIPOINT CONNECTION


Multipoint allows you to connect H10 to two separate devices at the same time.



1 Connect to the first device.




2 Turn off Bluetooth.



3 Press and re-enter pairing mode.



4 Connect to the second device.




5 Turn on Bluetooth on the first device and connect to H10 again.



RESET H10

- 1 Power on H10.
- 2 Press the power button and the volume down button at the same time, and hold for 5 seconds until you hear a voice prompt of "DuDu".




5"





FOLDING AND STORE



FAQ

Q: Can I still use H10 when the battery runs out?

A: Yes, you can plug in a 2.5mm audio cable to use them in wired mode.

Q: What should I do if H10 disconnects while in use?

A: Make sure that the distance between H10 and the device they're connected to is no greater than 33 feet (10 meters).

- Try to avoid interference from other Bluetooth connections and Wi-Fi. Some environments with cell phone towers or areas with dense Wi-Fi networks and other transmitting devices can interfere with your Bluetooth connection.
- Turn off your device's Bluetooth for at least 10s, then turn back on.
- Try to reset the headphone (see "Reset H10").
- Try to connect to another device to see if any difference.

FAQ

Q: What should I do if there is sound only playing from one side?

A: Please try to reset the headphone (see "Reset H10").

Q: Will H10 turn off automatically?

A: Yes, H10 will automatically turn off after 10 minutes if not connected to any device.

Q: How do I control the noise-cancelling functions?

A: Press the NC button to switch between different modes and you will hear a corresponding voice prompt of "ANC mode on", "ANC mode off", and "Ambient mode".



For more information, please visit:

www.tranya.com/support



For any assistance, email us:

support@tranya.com



Made in China

