

LAMPAOUS® LED Pool Bulb Installation

STEP 3. Inspect and service the bulb housing

Check the bulb housing, face plate, lens and gasket for signs of damage, wear, or deterioration. Inspect the location at which the cord enters the bulb housing for sign of damage, wear or deterioration. Do not install the LAMPAOUS® LED in-ground pool bulb in the bulb housing if there is damage, wear or deterioration. Instead, contact a pool professional regarding replacement of the bulb housing. Dry any water on the interior and external of the bulb housing, face plate, and lens. Clear any excess, rubber, sealant, or other material from the bulb housing and lens. It is strongly recommended that the old gasket be discarded and a new gasket may have indentations or other irregularities that could allow the water to leak from the pool into the bulb housing, risking equipment damage and serious injury or death by electrocution. The warranty is voided if a new gasket, proper replacement gasket is not used in the installation.

STEP 4: Install the LAMPAOUS® bulb replacement LED in-ground pool bulb in the bulb housing

Remove the old bulb from the bulb housing and dispose of it properly to local regulations. A threaded socket in the bulb housing will now be exposed. Holding the LAMPAOUS® replacement LED in-ground pool bulb, align the threaded base of the bulb with the threaded socket of the bulb housing, and screw the base i to the bulb housing. Do not over tighten.

STEP 5. Reassemble the bulb housing

Following the bulb housing's manufacturer's installation instructions, replace the gasket, lens, and face plate on the bulb housing. Ensure that the gasket is fully and continuously seated on the lens between the bulb housing and the face plate. It may be helpful to tighten screw slowly, and in an irregular order, to increase the chance that the gasket seals well. WARNING: Failure to ensure a continuous seal may result in damage to the bulb and serious injury or death. Without a continuous seal, water can leak from the pool into the bulb housing and risks equipment damage and electrocution.

STEP 6: Test the LAMPAOUS® bulb replacement LED in-ground pool bulb.

You may wish to test the LAMPAOUS® bulb replacement LED in-ground pool bulb at this point. Ensure that the bulb housing has been properly re-assembled and the bulb is electrically isolated before restoring power to the bulb. Working with electricity around water always presents a serious hazard. Only if bulb housing has been properly re-assembled and the bulb is electrically insulated, restore power to the bulb and turn it on to test the bulb installation. Turn the bulb off and disconnect power as in step 1 before proceeding further with Step 7.

STEP 7: Install the bulb housing in the niche assembly in the pool

After you have ensured that no power is currently being supplied to the bulb, place the bulb housing in the pool water and watch for the bubbles rising anywhere from the interior of the bulb housing or for the water entering the bulb housing. Bubble rising from the bulb housing or water entering the bulb housing, indicates that the gasket is not properly seated. Should you see the bulbs escaping or water entering, pull the bulb housing, as described above, Only after placing the bulb housing in the pool water without seeing rising bubbles or intruding water, re-install the bulb housing in the niche assembly in the pool per the bulb housing manufacturer's instructions.

STEP 8; Test and monitor the bulb

Restore power to the bulb and turn it on. For 10-15 minutes, leave the bulb on and monitor it. If your pool water is warm, it is recommended that you monitor the bulb for a longer period. Watch for bubbles rising anywhere from the interior of the bulb housing or water entering the bulb housing while the bulb is on. If no bubbles rise from the bulb housing and no water enter the bulb housing, the bulb and bulb housing should be properly installed. Should you see the bubble escaping or water entering, pull the bulb housing out of the water and remove and re-assemble the face plate, lens, and gasket on the bulb housing, as described above. Ensure that the LAMPAOUS® bulb replacement LED in-ground pool bulb and the bulb housing this re-assembly process. If bubble rise from the bulb housing or water enters the bulb housing despite repeat attempts at re-assembly, contact your pool professional for help, as additional maintenance to the bulb housing or niche assembly may be required.

OPERATION INSTRUCTION

The LAMPAOUS® bulb replacement LED in-ground pool bulb can be activated by flipping your pool light switch to the on position., and can be -de-activated by flipping your pool light switch to the off position. Each Model of LAMPAOUS® bulb replacement LED in-ground pool bulbs produces a different pool illumination. For instance some LAMPAOUS® bulb replacement LED in-ground pool bulbs deliver a vibrant, efficient, and multicolor lighting experience, while others deliver pure white illumination of your pool. Your LAMPAOUS® bulb replacement LED in-ground pool bulb may have unique settings and programs that you can use. For specific operation information please read Lampaous Co., Ltd " LAMPAOUS® Quick Start Guide" included with the bulb.

1-YEAR LIMITED WARRANTY

Products Warranty

LAMPAOUS warrants the LAMPAOUS® replacement LED in-ground pool bulb (the products) to be free from defects in material and /or workmanship, under normal use, conditions and service , for a period of one year from the original date of purchase. If during the warranty period, there is a defect in material or workmanship. LAMPAOUS will repair or replace (at its discretion) the products under the conditions of the warranty . The warranty covers normal consumer use of the product. To obtain warranty service contact LAMPAOUS at +86 135 487 084 88 or info@lampaous.com

Exclusions from warranty

The LAMPAOUS® bulb replacement LED in-ground pool bulb is designed for use in In-Ground swimming pools only. If installed for use in any other application, the warranty is void thereby releasing LAMPAOUS from any and all claims related to its misuse.. The warranty does not cover and LAMPAOUS shall be held harmless against and damage occurring during shipment, damage of failure resulting from alteration, accident, theft, abuse, negligent installation, improper service, unauthorized repairs or where adequate care has not been taken to prevent damage to the products Failure to install the proper gasket as specified in this installation manual will void the warranty. Tampering with any internal component of this products will void the warranty. This warranty does not cover failure due to presence of water inside the niche fixture. This warranty excludes all incidental or consequential damages except as required by state law. This warranty gives you specific rights. You may have other rights that vary according to the laws of your state.

© 2017 Hunan LAMPAOUS Electronic Co. Ltd. All rights reserved. LAMPAOUS® is a trademark of and manufactured by Hunan LAMPAOUS Electronic Co. ,Ltd. All registered and trademarked brands and names are the property of their respective companies.

No. 758 South Furong Road, Changsha, Hunan 410007, China
P:+86 135 4870 8488 Email intekit@lampaous.com www.lampaous.com