





USER'S MANUAL
FOR THE DIGITAL GAUGE
25MM STANDARD EDITION

NAME OF EACH PART




- **Display Area:** Shows pressure in Bar, shows battery icon when charging.
- **Touch-Key Area:** One button touch key
- **Magnetic Charging Connector:** 5V In
- **Snubber:** To protect pressure sensors and pressure gauges against pressure surges, if it is loose, use a flat-blade screwdriver to tighten it.
- **Vent Hole:** Explosion-proof, do not block this hole.




INSTALLATION

Before install the gauge on your air gun, choose the seal component properly.



A Complimentary Bonded Seal is **NOT** recommended on this gauge.



Pom/ PTFE/Rubber gaskets are recommended on this gauge.

Note: Using Pom/ PTFE/Rubber gaskets could possibly block the air inlet due to over-tightening, which may cause the gauge to read ZERO. Please make sure the air inlet is clear.

OPERATION

Power on: Short touch

Power off: Long touch for 5 seconds

Auto Power off: 10 minutes



To show the battery icon, you need to power on this device before charging it, and after the battery is fully charged, the battery icon does not change to indicate "FULL", this icon will disappear, and the device goes to sleep.

To extend the battery life, the whole charging process is divided into three-part, fast \ slow, and trickle charge. One or half hours of charging is enough for daily usage and it takes hours to wait for the icon to go off.

NOTES

THE COATING ON THE THREADS MAY HAD BEEN DAMAGED. THIS
DOESN' T MEAN THIS GAUGE HAS BEEN USED. IT WAS
SCRATCHED DURING THE TWO CALIBRATIONS AND PRESSURE
TESTS BEFORE WE SHIPPED IT.

SEKHMET
A i r g u n A c c e s s o r i e s