
№ WARNINGS

- Please read user manual carefully before using the light.
- Product will generate heat while working, please becautious with that to avoid any possible harm.
- Please don't shine into eyes directly to avoid harm to eyes.
- Please keep the light away from children.
- Please use WUBEN or WUBEN recommended batteries.
- Please don't disassemble the product or it will not be covered by WUBEN warranty policy. Please don't throw the product into fire.
- This is not a diving product, please don't use it underwater for a long time.

Before using this product, please check whether the contents of the package are complete.




x 1

Product operation


1. About product

Gecko E61 is a multifunctional penlight. The flashlight body can be rotated 270°, it emits 130 lumens max output, with red and blue beacon lights function. It has built-in a Li-polymer battery of 120 mAh, utilizes convenient Micro-USB charging design. The multifunctional pen is designed with 180° rotating hidden type. Both ends are optional to replace for stylus pen, ink-less pen, ballpoint pen, zirconium bead head, it can be easily and quickly replaced according to users' demands.



2. Installation

Replacement method of multifunctional pen.



3. Operation

- ON/OFF: Single click on
 witch to turn on the flashlight, click again to turn it off. Output selections and red and blue beacon lights have memory function when power off.
- Output Selections: When the flashlight is on, long press ® switch to cycle through Low -Med-High-Low. It will lockout the brightness once releasing the switch at any modes.
- Flash Modes: Double click on ® switch to activate red and blue beacon lights at any modes, long press ® switch to cycle through the main light modes, it will lockout the brightness once releasing. Single click to exit flash mode.

4.Breathing Light

When the flashlight is on or off, triple click@switch to turn on or turn off the blue breathing light. Standby for 5 days when the main light is off. It's used to easily find @switch in the darkness. It is recommended to turn off when not needed for saving battery power.

5.Lockout /Unlock

When the flashlight is off, 4 times click on @ switch, the main light blinks 3 times to indicate lockout status. Then any operations on @ switch will be invalid unless another 4 times click on @ switch, which will activate Low mode, to indicate unlocking of the flashlight.

6.Charging

Open the flashlight body, connect Micro-USB charging cable and adapter of 5V/1A to charge. It takes about 2 hours to be fully charged.



7. Charging Status Indication

Charging	Red light constant on
Charging finished	Blue light constant on

8.Battery Capacity (C) Status Indication

C ≥ 90%	Blue light constant on(off after 5 seconds)	
90% > C ≥ 40%	Blue light flashes(off after 5 seconds)	
40% > C ≥ 15%	Red light constant on(off after 5 seconds)	
15% > C > 0	Red light flashes	

Parameters

Parameters	High	Med	Low	Red and Blue Beacon Lights
314	130 ~ 40 Lumens	30 Lumens	3 Lumens	10 Lumens
0	1 + 45 mins	2.5 Hours	15 Hours	/
	8 Meters		√.	1 Meter
212	54g/1.9oz (without battery)		topo .	IP66
	143mm × 17.8mm × 12.5mm 5.63in × 0.7in × 0.49in (L×W×H)			

△ All data from experiments of WUBEN lab according to the quality test standard, may vary because of different experiment equipment, experiment environment or other factors. Experiments are based on a WUBEN Li-Polymer battery of 120 mAh.

Maintenance

- When it shows low power, please recharge it in time in order not to affect the use of the product.
- When not in use for a long time, please recharge it every 3 months to ensure the durability of the battery.
- Please cover the rubber piece of the USB ports well after recharging or discharging to avoid foreign matter.
- Please store the product in a dry and ventilated place.

FAQs

Problems	Causes	Solutions
Abnormal flash	Check if the switch is lockout	Unlock the switch
turn on	Check if the switch is turned on correctly	Turn on the switch
Abnormal noise Check if foreign matter falls in the tube Part damage		Pour out possible foreign matter
	Part damage	Contact your seller

If your problems still not solved yet, please contact WUBEN Headquarters for after-sales service.

Warranty policy

1. Warranty coverage

- 15 days replacement: Within 15 days from the date of purchase, if the product has quality problems, customers can request free replacement.
- 1 year warranty: Within 1 year from the date of purchase, if the product has quality problems, WUBEN will offer free repair.
- Battery warranty: WUBEN offers a 1-year warranty for the rechargeable batteries but other included accessories are not covered by the warranty.
- Lifetime maintenance: From the date of purchase, if the product has problem after 1
 years, WUBEN will offer paid repair for WUBEN registered customers.
- If proof of purchase cannot be provided, it will be counted on the date of manufacture.
- If there is any dispute, the two parties will coordinate to solve.

2. Beyond warranty

- Man-made damage.
- Damage caused by not following the instructions.
- Damage caused by improper use of the battery.
- Abnormal wear and tear
- Damage caused by irresistible factors.
- Gifts

The final interpretation right is reserved by WUBEN.

SHENZHEN SHENGQI LIGHTING TECHNOLOGY CO., LTD.

E-mail: support@wubenlight.com Web: www.wubenlight.com Add: 202#, Building A, Jihe E-Business Park, No. 33 Yangmei Road, Bantian Street. Longgano District. Shenzhen. China



