




## USER MANUAL

# True HEPA Air Purifier with Pollen Mode

Model: TR-8080B




## Questions or Concerns?

Dreamegg Support provides friendly services in 24 hours. Please contact us Mon-Fri at [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) if you need any help.

# PROTECT YOUR WARRANTY

Thank you for your purchase! Dreamegg Air Purifier comes with 365 days replacement warranty and 60 days money back guarantee, which starts from the purchase date of the order.

## Additional 6–Month Warranty

To extend your extra warranty 6 months and register your new Dreamegg, please email directly to  [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) with following information.

Your Name \_\_\_\_\_

Product Model \_\_\_\_\_

Amazon Order ID \_\_\_\_\_

Please complete your registration warranty as above. We will get back to with a confirmation email in 24 hours.



## Table of Contents

Package Contents	2
Specifications	2
Safety Information	3
Getting to Know Your Air Purifier	4
Controls	5
Getting Started	5
Using Your Purifier	6
About the Filter	8
Care & Maintenance	10
Troubleshooting	11
Warranty Information	13
Customer Support	13

## Package Contents

1	x	Air Purifier TR-8080B
1	x	True HEPA Filter (Pre-Installed)
1	x	User Manual

## Specifications

Power Supply	AC 100–110V, 50/60Hz
Rated Power	30W
Effective Range	≤23–28m <sup>2</sup>
Operating Conditions	Temperature: 14°–104°F / –10°–40°C
	Humidity: < 85% RH
Noise Level	23–50dB
Standby Power	< 0.5W
Dimensions	7.9 x 7.9 x 13.3 in / 20 x 20 x 34 cm
Weight	5.5lb / 2.5 kg

## READ AND SAVE THESE INSTRUCTIONS

### SAFETY INSTRUCTIONS

Failure to comply with the warnings listed below may result in electric shock or serious injury.



This product should only be used in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

When using electrical appliances, the following basic precautions should always be taken to reduce the risk of fire, electric shock and injury to persons.

Read all instructions before using appliance.

- **IMPORTANT** – This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- To avoid fire or shock hazard, plug the appliance directly into a correct AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, or near radiators, stoves or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids, and do not use near water.
- As children are not able to recognize the hazards associated with the usage of electrical appliances, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning, or whenever the air purifier is not in use. Be sure to unplug it by pulling on the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic areas where it will not present a tripping hazard.
- DO NOT operate any appliance with a damaged cord or plug, if the motor fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Get support from Customer Service for maintenance and repairs.
- Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- DO NOT use outdoors.
- DO NOT place anything on top of the unit.
- NEVER block the air openings, grills, outlets, or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outlet opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- **WARNING:** To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.

# GETTING TO KNOW YOUR AIR PURIFIER



## CONTROLS



### On/Off Button

- Turns the air purifier on/off.



### Night Light & Sleep Mode Button

- Turns the night light on/off
- Turns Sleep Mode on/off (see page 23).



### Fan Speed Button

- Cycles through fan speeds: I (low), II (medium), III (high) and Turbo speed.



### Check Filter Indicator

- Lights up when the filter should be checked (see page 22).



### UV-C Button

- Turns the UV-C light on/off (see page 23).



### Pollen Mode

- Run with level III fan speed for 10min and level II speed for 10min, then cycle through. Effectively traps allergens and purifies air.



### Timer Button

- Cycles through timer options (see page 22).



### Child Lock

- Prevent children and pets from accidentally tampering with it.


## GETTING STARTED

1. Flip over the air purifier. Twist the filter cover cap counterclockwise to remove it and set it aside.
2. Lift the filter cover off the purifier.
3. Remove the filter from its plastic packaging and place the filter back into the purifier.

**Note:** The filter does not have a top or bottom and can be installed either way.

4. Replace the filter cover and the cap. Twist the cap clockwise to lock.
5. Place the purifier on a flat, stable surface with the display facing up. Allow at least 30cm of clearance on all sides of the purifier. Keep away from anything that would block air flow, such as curtains.

# USING YOUR PURIFIER



## POWER ON/OFF

Slightly touch this button to turn on or switch off the unit.



## Filter Replacement Indicator

- 1.The filter light will light up yellow as a reminder to check & replace the filter.
- 2.The indicator should turn on Yellow within 6 months (4320 hours) continuous using, depending on how much you use the air purifier.



## Timer

- 1.Tap this button repeatedly to select a timer from 2, 4, 8 hours.
- 2.The air purifier will automatically power off once the timer is finished.
- 3.To cancel a timer, tap until all timer indicators are off, the unit will run continuously.

Continuously

Touch the button repeatedly until there are no more indicator lights lit up, it means you are in continuous mode.



## FAN SPEED

Tap the fan button to change fan speed between I, II, III and turbo.

- Turbo Fan Setting is the loudest but purify air quickest.
- To effectively purify air, please keep windows and doors closed while operating the air purifier.



## Pollen Mode

Run with level III fan speed for 10min and level II speed for 10min, then cycle through. Effectively traps allergens and purifies air.

- To exit pollen mode: Touch this Pollen button or fan button, the unit will be back to your previous settings.



## Night light

1. Tap once, it turns in full brightness.
2. Tap a second time, it turn in dim brightness.
3. Tap a third time, it turns off.



## Sleep Mode

1. Hold and Press this button for 2.5 seconds to turn on sleep mode, all light indicator flash 3 times and then goes off.
2. At sleep mode, it operates quietly by using the lowest possible fan speed.

- Note:**
- All indicators and night light will turn off when in Sleep Mode.
  - The air purifier will automatically turn off if you set any timer.
  - Sleep mode will not be remembered after re-plugging the unit.



## UV-C light

Slightly touch this button to turn on or switch off the UV-C light.



## Child Lock

1. Hold and Press the button for 2.5 seconds to turn on/off the child lock function.
2. When child lock function is activated, all modes can not be changed, only power button works.

- Note:**
- When the unit is in sleep mode, tapping the child lock button will not activate the lock function. It will cancel sleep mode first, then you need to long press around 2.5 seconds to activate the child lock.



# ABOUT THE FILTER


The air purifier uses a 4-stage filtration system to purify air.

## A. Pre-Filter

- Captures large particles such as dust, lint, fibers, hair, and pet fur.
- Maximizes the filter's life.

## B. STERILIZATION FILTER

- Since it contains a component that suppresses the growth of bacteria and viruses, it removes bacteria and viruses in the filtered air.



## C. True HEPA Filter

- Removes at least 99.97% of airborne particles 0.1 micrometers ( $\mu\text{m}$ ) in diameter.
- Filters small particles such as smoke, tiny dust particles, mold spores, bacteria, viruses, and allergens such as pollen, dander, and mites.

## D. High-Efficiency Activated Carbon Filter

- Physically adsorbs unwanted odors and fumes.

## Humidity


Moisture may damage the filters. This air purifier should be used in an area with a humidity level below 85% RH. If you use the air purifier in excessively humid areas, the surface of the filter will become moldy.

**Note:** Water or moisture will allow mold to grow. Air purifiers cannot solve an existing mold problem, only remove mold spores and reduce odors.

## Essential Oils

**Do not** add essential oils to the air purifier or filter. The filter will become damaged by the oil and will eventually release an unpleasant smell. **Do not** use oil diffusers near the purifier.



## When Should I Replace the Filter?

The filter should be replaced every 6–12 months. You may need to replace your filter sooner or later depending on how often you use your air purifier. Using your air purifier in an environment with relatively high pollution may mean you will need to replace the filter more often, even if  is off.

You may need to replace your filter if you notice:


- Increased noise when the air purifier is on
- Decreased airflow
- Unusual odors
- A visibly clogged filter

### Note:

- If your home has high air pollution, you may need to change your filter before  lights up.
- Remember to reset  after changing the filter.

## Check Filter Indicator

The indicator will light up as a reminder to check the filter. Depending on how much you use the air purifier, the indicator should turn on within 6–12 months. You may not need to replace your filter yet, but you should check it when the light turns on.









-  The indicator should turn on Yellow within 6 months (4320 hours) continuous using, depending on how much you use the air purifier.

## Replacing the Filter

1. Unplug the air purifier. Flip the air purifier over and remove the filter cover cap and filter cover (see **Getting Started**, page 21).
2. Remove the old filter.
3. Clean any remaining dust or hair inside the purifier using a vacuum hose. **Do not** use water or liquids to clean the purifier.
4. Unwrap the new filter and place it into the housing (see **Getting Started**, page 21).
5. Replace the cover and cap. Plug in the air purifier.
6. Reset the Check Filter Indicator.

## Resetting the Filter Indicator

Reset the Filter Indicator when:

- A.  lights up.
  1. Replace the filter.
  2. Turn on the air purifier.
  3. Press and hold  for 2.5 seconds.
  4.  will turn off when successfully reset.
- B. The filter was changed before  lit up.
  1. Press and hold  for 2.5 seconds. This will turn on .
  2. Press and hold  again for 2.5 seconds.
  3.  will turn off when successfully reset.

# CARE & MAINTENANCE

## Cleaning the Air Purifier

- Unplug before cleaning.
- Wipe the outside of the air purifier with a soft, dry cloth. If necessary, wipe the housing with a damp cloth, then immediately dry.
- Vacuum the inside of the air purifier.
- **Do not** clean with abrasive chemicals or flammable cleaning agents.



## Cleaning the Filter








The True HEPA Filter should be cleaned once a month to increase the efficiency and extend the life of your filter. Clean the inside and outside of the filter using a soft brush or vacuum hose to remove hair, dust, and large particles. **Do not** clean the filter with water or other liquids.

## Storage

If not using the air purifier for an extended period of time, wrap both the purifier and the filter in plastic packaging and store in a dry place to avoid moisture damage.

# TROUBLESHOOTING

Problem	Possible Solution
Air purifier will not turn on or respond to button controls.	Plug in the air purifier.
	Check to see if the power cord is damaged. If so, stop using the air purifier and contact <b>Customer Support</b> (see page 13).
	Plug the air purifier into a different outlet.
	Air purifier is malfunctioning. Contact <b>Customer Support</b> (see page 13).
Airflow is significantly reduced.	Make sure the filter is removed from its packaging and properly in place (see page 5).
	Tap  to increase the fan speed.
	Make sure there are at least 30 cm of clearance on all sides of the air purifier.
	Replace the filter (see page 9).
Air purifier makes an unusual noise while the fan is on.	Make sure the filter is properly in place with plastic packaging removed (see page 5).
	Make sure the air purifier is operating on a hard, flat, even surface.
	Replace the filter (see page 9).
	The air purifier may be damaged, or a foreign object may be inside. Stop using the air purifier and contact <b>Customer Support</b> (see page 13). Do not try to repair the air purifier.
Poor air purification quality.	Tap  to increase the fan speed.
	Make sure no objects are blocking the sides or top of the air purifier (the inlet or outlet).
	Make sure the filter is removed from its packaging and properly in place (see page 5).
	Close doors and windows while using the air purifier.
	Make sure the room is smaller than 269 ft <sup>2</sup> / 25 m <sup>2</sup> . The air purifier may not be as effective in larger rooms.
	Replace the filter (see page 9).


Problem	Possible Solution
Strange smell coming from the purifier.	Clean the filter or replace if necessary.
	Contact <a href="#">Customer Support</a> (see page 13).
	Make sure not to use your purifier in an area with high humidity or while diffusing essential oils.
 is still on after replacing the filter.	Reset the Check Filter Indicator (see page 9).
 has not turned on within 8 months.	 is a reminder for you to check the filter and will light up based on how long the air purifier has been used (see page 9). If you don't use your air purifier often,  will take longer to turn on.
 turned on before 6 months.	 is a reminder for you to check the filter and will light up based on how long the air purifier has been used (see page 9). If you run your air purifier frequently,  will turn on sooner.
Air does not flow evenly out of the air purifier.	This is due to the design of the air purifier. This is normal and will not affect the air purifier's efficiency.

If your problem is not listed, please contact [Customer Support](#) (see page 13).

## WARRANTY


Dreamegg air purifier come with 365 days replacement warranty and 60 days money back guarantee, which starts from the purchase date of the order. A defect arises and a valid claim is received within the warranty period at its option. Dreamegg will replace the product with a new item.

Obtaining Service:

To obtain warranty service , please email to  [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) with your order ID to register.


## Defective Products & Returns

1.Would love a replacement for defective products?

Should your product is defective within the specified warranty period, please contact us via  [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) with order number. Once our customer support team hear from you, we will process your request in 24 hours.

2.Not happy with the unit or passed Amazon 30 days return window?

No worries! Be sure to contact Dreamegg customer service at

 [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) with your order number. we will process your request faster and easier, usually in 24 hours.

## CUSTOMER SUPPORT

 [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com)

Need help? Contact us directly at [supportjp@mydreamegg.com](mailto:supportjp@mydreamegg.com) with your order ID.

We are more than happy to serve you in 24 hours. Dreamegg support is here to make sure you are completely satisfied with your product.



*Dreamegg*