

<div>AIR PURIFIER</div>	<div><div>INSTRUCTION MANUAL</div><div><div><div>AIR PURIFIER</div><div>Model:Miro</div></div></div></div>														
<div><div>Thank you very much for using our products. Please read the user manual carefully before use, and keep it for future reference.</div><div>v0</div></div>	<div><div>Zhongshan Invitop Electrical Co., Ltd B-6F, No.6 Xinhua Road, Sanjiao Town, Zhongshan City, Guangdong P.R.C</div></div>														
<div><div>CONTENT</div><div><div>Points for Attention</div><div>Product Overview</div><div>Specifications</div><div>Installation Filter</div><div>Function Instruction</div><div>Maintenance</div><div>FAQ</div></div><div><div>01</div><div>02</div><div>04</div><div>04</div><div>06</div><div>08</div><div>09</div></div></div>	<div><div>POINTS FOR ATTENTION</div><div>Before using, please read this user manual carefully and keep it for future reference.</div><div><div>Warning</div><div><div>1. To avoid electric shock and fire, do not allow water, liquid or any flammable detergent to get into or to clean the product.</div><div>2. Do not spray insecticide, perfume or other flammable spray around the products.</div><div>3. Before connecting the power supply, please check whether the voltage of the product is consistent with the local power supply voltage.</div><div>4. This product can not replace normal ventilation, daily dust collection or oil pumping when cooking.</div><div>5. Ensure the product is used in condition of a stable and horizontal level.</div><div>6. Leave at least 30cm of space on the back and sides of the product, and at least 50cm of space above the product when using.</div><div>7. Ensure both the filter and its cover are properly installed before using.</div><div>8. Do not insert finger or other things into the air outlet/inlet to prevent physical damage or trouble.</div></div></div><div>01</div></div>														
<div><div>PRODUCT OVERVIEW</div><div><div>Components</div><div><div><div><div>Air Outlet</div><div>Control Panel</div><div>LED Light</div><div>Air Inlet</div></div><div><div>Filter</div><div>Base</div></div></div></div></div><div>02</div></div>	<div><div>Control Panel</div><div><div><div><div><div></div></div><div>Power Button</div></div><div><div><div></div></div><div>Timer Button</div></div><div><div><div></div></div><div>Wind Speed Button</div></div><div><div><div></div></div><div>Light Control Button</div></div></div></div></div> <div>03</div>														
<div><div>SPECIFICATIONS</div><table><tr><td>Model No.</td><td>Miro</td></tr><tr><td>Size</td><td>195*195*388mm</td></tr><tr><td>Net weight</td><td>2kg</td></tr><tr><td>Adapter</td><td>Input:100-240V 50Hz-60Hz; Output:24V-1.2A</td></tr><tr><td>Power</td><td>23W</td></tr><tr><td>Noise</td><td>< 55dB</td></tr><tr><td>Coverage area</td><td>≤16㎡</td></tr></table><div><div>INSTALLATION FILTER</div><div><div>Notice:</div><div><div>• Please remove the packaging of the filter before using for the first time.</div><div>• Ensure the machine is unplugged before removing or installing the filter.</div><div>• When the LED light keeps flashing in red, the filter should be replaced.</div><div>• Please wipe the dust on the filter regularly, do not wash or use it repeatedly.</div><div>• Please use the filter specially designed for this product.</div></div></div><div><div>Steps of Installing Filter:</div><div>Unplug the power socket of the machine before replacing or installing the filter.</div></div></div><div>04</div></div>	Model No.	Miro	Size	195*195*388mm	Net weight	2kg	Adapter	Input:100-240V 50Hz-60Hz; Output:24V-1.2A	Power	23W	Noise	< 55dB	Coverage area	≤16㎡	<div><div><div><div><div><div>①</div><div>Open</div></div><div><div>②</div></div><div><div>③</div><div>Packaging</div></div></div><div><div><div>④</div></div><div><div>⑤</div><div>Close</div></div></div></div><div><div>1. Invert the machine, and rotate the base along the direction marked "OPEN"</div><div>2. Take out the filter from the machine.</div><div>3. Remove the packaging of the filter</div><div>4. Install the filter into the machine.</div><div>5. Then install the base, rotate and tighten the base along the direction marked "CLOSE"</div><div>Notice: Please press the power button for 7s to reset after installing a new filter.</div><div>(When using the device for the first time, should remove the packing of filter before using but do not reset the device.)</div></div></div><div>05</div></div>
Model No.	Miro														
Size	195*195*388mm														
Net weight	2kg														
Adapter	Input:100-240V 50Hz-60Hz; Output:24V-1.2A														
Power	23W														
Noise	< 55dB														
Coverage area	≤16㎡														
<div><div>FUNCTION INSTRUCTION</div><div><div>Insert the plug into the power socket, the buzzer will ring for 1 time with all the button indicator lighting in BLUE for 1 second and then go off,which indicates the device connects with power.</div><div><div><div><div></div></div><div>Power Button</div></div><div><div>① Press the power button to turn on the device; The buzzer rings for one time, and the power indicator, low-mode indicator, and LED light will be in BLUE.The device starts to work at the low mode by default.</div><div>② Press the power button again, the buzzer will ring for one time and the device will turn off with all lights off.</div><div>Notice: In the case of connecting power, turn it off and then turn it on again. The device defaults to the working state before shutdown.</div></div><div><div><div><div></div></div><div>Wind Speed Button</div></div><div><div>① In the condition of working, press the wind speed button, the buzzer will ring for one time,</div><div>② Press again to adjust the wind speed among the circulation of Low mode, Middle mode and High mode with buzzer rang, the corresponding indicator will be on.</div><div>Notice: The wind speed adjustment couldn't operate in the status of shutdown</div></div></div></div></div><div>06</div></div>	<div><div><div><div><div></div></div><div>Timer Button</div></div><div><div>① In the condition of working, press the timer button to set among the circulation of 2H, 4H and 8H timer with buzzer rang, and the corresponding indicator will be on.</div><div>② After one circulation of timer setting,press it again,the device will keep working.</div><div>③ In the status of timing, the machine begins to count down. When the time is up, the device will stop working and all lights will be off.</div><div>Notice: The timer button couldn't operate in the status of shutdown</div></div><div><div><div><div><div></div></div><div>Night Light Button</div></div><div><div>① Press the light button in the standby state, the LED light will be off.</div><div>② Press for second time, the buzzer will ring for one time and the LED light will turn into soft mode.</div><div>③ Press for third time, the buzzer will ring for one time and the LED light will turn into standard mode.</div><div>④ Press it again, the LED light will be off.</div></div></div></div><div>07</div></div></div>														
<div><div>MAINTENANCE</div><div><div>Note</div><div><div>• Ensure the machine is unplugged before maintenance.</div><div>• Do not t immerse the air purifier into water or any liquid.</div><div>• Do not use abrasive, corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the unit.</div><div>• Do not wash the filter.</div><div>• Do not use a vacuum cleaner to clean the filter.</div><div>• Please sterilize the filter under sunlight regularly.</div></div><div><div>Cleaning & Storage</div><div><div>① Ensure the machine is power-off and unplugged.</div><div>② Use a soft cloth with neutral cleanser to clean away any dust or debris from the surface of the machine and air inlet/outlet.</div><div>③ After the machine completely dry out, put on the bag and place it in a cool and well-ventilated place.</div><div>④ If you do not use it for a long time, please turn on the machine for a few minutes from time to time to ensure a good performance.</div><div>Notice: Please don't drop any water into the machine when clean the air outlet.</div></div></div></div><div>08</div></div>	<div><div>FAQ</div><table><tr><th>SITUATION</th><th>REASON</th></tr><tr><td>No working</td><td><div><div>• Is it plugged into a power socket? Is there a power outage?</div><div>• Is the home leakage switch or fuse cut off?</div><div>• Is the filter replacing indicator keep flashing?</div></div></td></tr><tr><td>Poor performance</td><td><div><div>• Is there any dust in the surface of pre-filter?</div><div>• Is there any obstacle blocking the air inlet/outlet.</div></div></td></tr><tr><td>Significant noise</td><td><div><div>• Is there anything stuck on the fan in the air outlet?</div><div>• Is the machine tilted?</div><div>• Please set a lower grade of wind speed if the noise is too loud , or set low grade of wind speed when using in bedroom at night.</div></div></td></tr><tr><td>Coming out nasty smell</td><td><div><div>• It is the normal phenomenon that the machine emits the smell of plastic for the first time. The machine will emit nasty smell if the filter is dusty, so in this situation, please clean or replace the filter.</div><div>• If the burning smell emits from the machine, please unplug the power socket and contact with buyer or customer service.</div></div></td></tr><tr><td>The reminder of replacing filter is still flashing after user have replaced a new one.</td><td><div><div>• Please press the power button <div></div> for 7s to reset the machine and the life counter of the filter will start.</div></div></td></tr></table><div>Notice: If the above FAQ can not solve your problems and need maintenance, please contact the supplier or after sales service center. Please do not disassemble the machine to maintain by yourself.</div><div>09</div></div>	SITUATION	REASON	No working	<div><div>• Is it plugged into a power socket? Is there a power outage?</div><div>• Is the home leakage switch or fuse cut off?</div><div>• Is the filter replacing indicator keep flashing?</div></div>	Poor performance	<div><div>• Is there any dust in the surface of pre-filter?</div><div>• Is there any obstacle blocking the air inlet/outlet.</div></div>	Significant noise	<div><div>• Is there anything stuck on the fan in the air outlet?</div><div>• Is the machine tilted?</div><div>• Please set a lower grade of wind speed if the noise is too loud , or set low grade of wind speed when using in bedroom at night.</div></div>	Coming out nasty smell	<div><div>• It is the normal phenomenon that the machine emits the smell of plastic for the first time. The machine will emit nasty smell if the filter is dusty, so in this situation, please clean or replace the filter.</div><div>• If the burning smell emits from the machine, please unplug the power socket and contact with buyer or customer service.</div></div>	The reminder of replacing filter is still flashing after user have replaced a new one.	<div><div>• Please press the power button <div></div> for 7s to reset the machine and the life counter of the filter will start.</div></div>		
SITUATION	REASON														
No working	<div><div>• Is it plugged into a power socket? Is there a power outage?</div><div>• Is the home leakage switch or fuse cut off?</div><div>• Is the filter replacing indicator keep flashing?</div></div>														
Poor performance	<div><div>• Is there any dust in the surface of pre-filter?</div><div>• Is there any obstacle blocking the air inlet/outlet.</div></div>														
Significant noise	<div><div>• Is there anything stuck on the fan in the air outlet?</div><div>• Is the machine tilted?</div><div>• Please set a lower grade of wind speed if the noise is too loud , or set low grade of wind speed when using in bedroom at night.</div></div>														
Coming out nasty smell	<div><div>• It is the normal phenomenon that the machine emits the smell of plastic for the first time. The machine will emit nasty smell if the filter is dusty, so in this situation, please clean or replace the filter.</div><div>• If the burning smell emits from the machine, please unplug the power socket and contact with buyer or customer service.</div></div>														
The reminder of replacing filter is still flashing after user have replaced a new one.	<div><div>• Please press the power button <div></div> for 7s to reset the machine and the life counter of the filter will start.</div></div>														