


H4M  
Helmet Headset  
User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.


## Caring For Your MOMAN Product

1. Please keep the product in a dry, clean, dust-free environment.
2. Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
3. Use only a soft and dry cloth for cleaning the product.
4. Malfunction may be caused by dropping, impact of external force.
5. Do not attempt to disassemble the product. Doing so voids warranty.
6. Please have the product checked or repaired by authorized technicians if any malfunctions happened.
7. Failure to follow all the instructions may result in mechanics damage.
8. Warranty does not apply to human errors.


## Package List




H4M Helmet Headset x1




Back Clip x1



Velcro Clip Kit x1



Changeable hard mic and soft mic speakers x1




Type-C Charging Cable x1



User Manual x1

## Product Instruction



- |                             |  |
|-----------------------------|--|
| ① Volume down/Previous song | ⑤ LCD display                              |
| ② Volume up/Next song       | ⑥ Mode key(Bluetooth/FM radio/Temperature) |
| ③ On/Off key                | ⑦ Speaker/Microphone Interface             |
| ④ AI voice assistant        | ⑧ Charging Interface                       |

### \* Note:

Before installing the headsets, follow the Quick Manual instructions to connect your phone and audition the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

### LCD Icon



Quantity of electricity



Play



Bluetooth



Pause



Volume



Temperature in Centigrade



FM radio signal




Temperature in Fahrenheit

## Operation

### 1. Power On/Off

#### ① Power On




Press and hold for 3 seconds




Indicator light on

#### ② Power Off



Press and hold for 3 seconds



Indicator light off

### 2. Bluetooth Connection




Bluetooth not connected:  
Bluetooth icon flashes quickly

Voice Prompt



Bluetooth connected:  
Bluetooth icon keeps on

### 3. Language Switch



Double click (Bluetooth not connected)

English ↔ Japanese

### 4. Phone Control

#### ① Automatic Answering Mode

Double click the Volume up key to switch between manual answer and automatic answer(When Bluetooth not connected).



Incoming call



After 10 seconds



Automatic Answer



Short press



End the call

#### ② Manual Answering Mode



Incoming call



Short press



Answer



Short press



End the call




Press and hold for 2 seconds




Reject the call

### ③ Redial the last call





### 5. Music control




### 6. EQ Mode

Long press to switch between 6 sound effects




### 7. FM Radio


1. Short press to switch up the saved radio station (In FM mode)
2. Short press to switch down the saved radio station (In FM mode)
3. Short press to search for radio stations automatically (Automatically save stations after searching) (In FM mode)
4. Long press to switch between Bluetooth and FM modes
5. Short press to enter or exit mute (In FM mode)



### 8. Ai Voice Assistant



### 9. Charging mode



### Specifications

Connection Distance with Mobile	20m
Bluetooth Version	5.3
Bluetooth Name	MOMAN H4M PLUS
Bluetooth Protocol	A2DP ,AVRCP
Charging Port	Type-C
Standby Time	360H
Working Time	32H
Battery	3.7V/1000mAh Lithium Battery
Charging Time	2H
Charging Voltage	5V
Speaker Diameter	40mm
Frequency Range	2.4GHZ
Temperature Range	-20~50°C

### Instruction warning

#### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### Moman (UK) Limited

Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX  
www.momanx.com  
@MomanGlobal  
https://moman.co/youtube