
MOMAN



MLQ-RGB Photography Fill Light

User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.

Package List





Bag x1

Mount x1





Cable x1



Manual x1

Product Introduction



- (1) Charging Port: Type-C Port
- ② Mode Switch Button: Press the button to switch light modes (CCT, HSI, EFF mode)
- Power Button: Long press to turn on/off the product.
- 4 Mode Display: The indicator would turn on blue when a correspondent mode is selected
- (5) Battery Bar: Remaining battery display.

- 6 Multi-function Button
- 7 Brightness Button: 0%-100%. Press up to increase brightness, press down to decrease brightness. (Note: Brightness Button does not apply to EFF mode.)
- (8) 1/4" Mounting Screw Hole: For connecting with ball head, tripod, hot shoe.

Operations

CCT Mode

Feature:

Color temperature: 3000K~6500K

Indicator:

When in CCT mode, the indicator stays on blue: When the color temperature reaches highest/lowest. the indicator fast flashes:

When the brightness is 0%, the indicator slow flashes.

Muti-function Button:

For adjusting the color temperature. Press up to increase color temperature, down to decrease color temperature.

HSI Mode

Feature:

RGB full color, color range: 0°-360°

Indicator:

When in HSI mode, the indicator stavs on blue: When the brightness is 0%, the indicator slow flashes.

Muti-function Button:

For adjusting the color saturation. Press up to increase values, press down to decrease values. Press to switch among CCT. HSI and FFF



Press to switch among CCT. HSI and FFF





MLO-RGB 说明书转曲EN-340x100mm.indd 1 2021/5/24 17:56:29

FFF Mode

Feature:

Altogether 21 special effects, 7 subordinate modes: Warning → Colorful lights → Party → Music → Fire → Photo → Lighting

Indicator:

When in HSI mode, the indicator stays on blue.

Multi-function Button:

For adjusting the color saturation, Press up/down to adjust the effect.

90 pieces

Ra>95

>120°

5W

3000K~6500K

- 1) Warning (1-3)
- 2) Colorful lights (4-6)
- 3) Party (7-9)
- 4) Music (10-12)
- 5) Fire (13-15)
- 6) Photo (16-18)

Specification

Number of LEDs

Color Temperature Range

Color Rendering Index

Max Output Power

Emitting Angle

7) Lighting (19-21)





Maintenance

- 1. Please plug out the USB charging cable when charging finishes.
- 2. If you do not use this product for a long time, it might not be able to turn on instantly, which is due to dead battery. Please charge the product and it can resume to work. Please charge the product every 3 months regularly.
- 3. This product has built-in rechargeable Li-ion battery which has limit to longevity, and when the performance degrades in years use, please contact us to get the battery replaced.
- 4. Please do not drop or impact to avoid scratches on the surface.
- 5. This product is not water-proof.

Notes

1. Please do not disassemble or modify the product.

- Press to switch among CCT HSI and FFF
- Runtime 100% brightness for about 2 hours Built-in Li-ion Battery Capacity 2300mAh Charging Port Type-C Input Voltage 5V/1A Charging Time >2 hours Body Material Aluminum Allov Weight 145a Dimension 114x58 5x16mm
- 2. Please do not submerge the product or put it in fire.
- 3. Please avoid impact on the product.
- 4. This product might become hot during usage which is normal, please allow certain space for heat-sink when using it.
- 5. Please do not put the product under high temperature or high humidity.

Warrantv

A one-year limited standard warranty is provided for products with quality problems under normal use (non-human damage) from the date of sale.

Moman (UK) Limited

- Quantity of the Property of Kingdom BH23 6NX
- @ www.momanx.co.uk
- https://moman.co/youtube

MLO-RGB 说明书转曲EN-340x100mm.indd 2 2021/5/24 17:56:30