SYNCO




Microphone P2T/P2L >>> User Manual


Thank you for choosing SYNCO product. Please read this manual carefully before use and follow all instructions mentioned herein.

Caring For Your SYNCO Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.



Product Instruction



TX Transmitter

- ① Power
- ② Working Indicators

Working

Indicators(White

Light)

Indicators(Red Light)

Flash concurrently

.

two-way >> >> • « « «

Indicator — Wireless Charging Case

Indicators(White Light)

Working

Illuminate sequentially

Indicator - Receiver

Indicators

Light)

- (3) Built-in Mic
- (4) Contacts
- ⑤ Pocket Clip

① Vocal Effects/ Mono/Stereo

② Type-C Port

System unpaired

Low battery

System unpaired

Mono mode-Original sound

Mono mode-Vocal effects on

Stereo mode (Only original is supported)

System paired

Pairing

System paired, normal working

Charging, and then turns off when fully charge

- ③ Working Indicators
- (4) Connector
- (5) Contacts

RX Receiver

Indicator — Transmitter (Double press the Power button to turn off light effect)

Illuminate sequentially(light effect on)

Single light keeps on (light effect off)

Single light keeps on (in the case)

Flash concurrently

~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~

Single light flashes

Single light keeps on & Illuminate sequentially

Single light keeps on & Illuminate sequentially

Single light flashes twice & Illuminate sequentially

Illuminate sequentially

Wireless Charging Case

- 1) Pairing/Power Prompt ② Type-C Port
- ③ Working Indicators
- (4) Contacts

(Forcible switch: Long press the Power button on TX for 3 seconds)

1) Tap on the right side of charging case to pop out the drawer

RX should boot automatically as it is plugged into smartphone

2. Pairing

1. Usage

Operations

② Take the TX and RX out

when returning to the case.

① Place the TX and RX in the case with their contacts are connected with the case's

3 TX should boot automatically as it leaved the case, and switch itself off automatically

- ② Long press the Pairing button on the case for 3 seconds with the drawer open
- 3 The indicators on the TX and RX should light up and illuminate sequentially when pairing is successful

Note: The transmitter will automatically switch off if it is unpaired or disconnected for 5

3. Charging

Charge the TX: Place the TX in the case with contacts connected with the case's. Charge the case: Connect the case with power supply via the charging cable.

4. Check the power

TX: Short press the Power button, the indicators will light up according to remain power for 5 seconds

Charging Case: Short press the Power Prompt button, the indicators will light up according to remain power for 5 seconds

Use vocal effects

Short press the Vocal Effects button on the receiver to switch sound effects: Original >> Studio FX >> KTV FX >> Voice Amplification >> EDM (Electronic Dance Music) >> Baby FX >> Male to Female >> Female to Male >> Monster FX. Default effect: Original

Note: The vocal effect will apply to both transmitters. In Stereo mode, only original is supported. Other vocal effects are unavailable.

6. Mono/ Stereo

Long press the Mono/Stereo button on the RX once Long press the Mono/Stereo button on the RX once







7. Charging phone device

Plug your phone charging cable into the Type-C Port on the receiver.

8. In-Ear monitoring

Plug the included Type-C to 3.5mm Adapter into the Type-C Port on the receiver. Then plug in your headphones to real-time monitor mic recording and device's backgrounding.

Note: The included Type-C to 3.5mm Adapter is exclusive, not available for other devices.

Specifications

TX Transmitter

Wireless Transmission	Digital 2.4GHz
RF Frequency Band	2400-2483.5MHz
Frequency Response	20Hz-20KHz
Working Distance	492ft/150m(LOS area); 164ft/50m(NLOS area)
Sampling Rate	48KHz
Bit Depth	16Bit
Sensitivity	-26dB
SNR	>75dB
RF Output Power	10dB
Battery Type	Built-in Lithium Battery, 120mAh
Battery Charging Time	1.5H
Battery Life	5H
Dimensions	49x19x19 (mm)
Material	ABS
Weight	10g

RX Receiver

Wireless Transmission	Digital 2.4GHz
RF Frequency Band	2400-2483.5MHz

Working Distance	492ft/150m(LOS area); 164ft/50m(NLOS area)
Sampling Rate	48KHz
Bit Depth	16Bit
Antenna	Built-in
Monitoring	3.5mm In-Ear Monitoring
Connector	Type-C or Lightning Output
Power Input	Type-C
Dimensions	49x30x9 (mm)
Material	ABS
Weight	5g

Wireless Charging Case

	Battery Type	Built-in Lithium Battery, 700mAh
	Battery Charging Time	2H
	Charging Port	Type-C Port
	Power Requirements	5V 2A
	Dimensions	70x68x38mm
	Weight	87.5g

Warranty

Warranty Period

Thank you for purchasing SYNCO products.

- 1. Customers are entitled to free replacement or repair service in case of quality defect(s) found in the product under normal use within 30 days upon receipt of the product.
- 2. Original SYNCO products are entitled to 12-month limited warranty service. The warranty period begins on the date of purchase of brand new, unused products by the first end-user.

Within the warranty period, if product defect or failure is attributable to material defection or technological problem, the defective product or defective part will be repaired or replaced without charge (service and materials fee).

Warranty Exclusions and Limitations

- Faults resulted from inappropriate use of a product without following its operation specification
- Artificial damage, e.g. crash, squeeze, scratch, or soaking
- Modifications to a product by its user or a third party without prior written consent of SYNCO, e.g. replacement of element or circuit, label alteration
- The code on product is inconsistent with that of warranty certificate, or the code on the product or warranty certificate
 is altered or torn off
- All consumable accessory attached to a product, like cable, wind muff, battery
- Faults as a result of force majeure, such as fire, flood, lightning, etc.

Warranty Claim Procedure

- If failure or any problem occurs to your product after purchase, please contact a local agent for assistance, or you can always contact SYNCO's customer service through email at support@syncoaudio.com.
- Please retain your sales receipt and warranty certificate as proof of purchase. If any of these documents is missing, only sales return or chargeable service will be provided.
- If the SYNCO product is out of the warranty coverage, the service and the parts cost will be charged.

WARRANTY CERTIFICATE Please register your warranty. Meanwhile, you are welcomed to contact us via Email: support@svncoaudio.com Customer Name: Phone Number: USER INFORMATION Email: Address: Sales Date: Model: SALES INFORMATION Product Code: Dealer: Service Date: Technician: REPAIR RECORD Issue. RESULT □ Returned(Replaced)

Guangzhou Zhiying Technology Co., Ltd

- Block 15th, No.200 Fangcun Avenue East, Liwan District, Guangzhou, China, 510000
- support@syncoaudio.com
- www.svncoaudio.com
- https://www.facebook.com/svncomicrophones