
INSTRUCTION MANUAL



SAFETY INFORMATION

IMPORTANT: Read all safety precautions and installation instructions carefully before installing

- ◆Do not install the fixture with power on, also do not operate by wet hands.
- ◆Ensure the fixture is mounted onto a good structurally surface that will support the fixture.
- ◆The fixture is designed for use in 120VAC, 60Hz.
- ◆Product can be used in shops, supermarkets, Hospitals, airports, office buildings, government buildings etc.
- ◆Do not install on radiant-heating type ceiling.

WARNING: IF NOT FOLLOW THESE INSTRUCTION MAY LEAD TO A POTENTIALLY FATAL ELECTRICAL SHOCK OR PROPERTY DAMAGE

PRE-INSTALLATION

HARDWARE INCLUDED











AA: large Pointed Pin Cross

BB: Wall Anchors*4PCS

CC: Wire Nut*3PCS

DD: Ceiling Hook*2PCS

EE: Hanging Chain*2PCS

Wood Screws*4PCS









GG: Ceiling flush mounted sheet*2PCS

NSTALLATION (Suspended Mounting)


1. Based on the dimension as below, put the expansion screws (BB) into ceiling or wall. Fix the ceiling hook (DD) to the ceiling.




3. Connect AC wire.



2. One end of the hanging chain (EE) fixed to the ceiling hook (DD) and the other end hung to the fixture (Part A). Adjust the hanging chain to make the two ends of fixture keep balance.




4. Lock the wiring pipe to the fixture, installation complete.




INSTALLATION (Flush Mounting)


1. Refer to the dimension of the lighting fixture, install the buckles (EE) to the ceiling.




3. Connect AC wire.



2. Lock the mounting plate.




4. Pull up the light fixture to put it on the buckles.




INSTALLATION (Linkable)


1. Knock off the knockouts at the end of the product.




2. Take off the PC cover from the fixture.




3. Following above installation to fix the fixture first and takes on the radiator from the fixture. (Safety rope to avoid the radiator falling down.) Connect all the wires inside the fixture, and extend the wires which need to be connected from the knockout.



4. Reinstall the radiator and PC cover to the fixture after wiring connection.



5. Linkable connection finish.



Guarantee

If your product does not arrive in good condition or does not work great 100%Satisfaction Guarantee within 3 years, please let us know we will give you replacement or refund. Customer service: **Lightdot.cs@hotmail.com**