

WARNING

CHOKING HAZARD

Small parts can be swallowed and block the airway.
Do not allow children under the age of 3 to use this product.


Use under adult supervision at all times.

FIRE HAZARD

Keep all flame and heat sources away from tent fabric.

Assembly and usage guidelines:

- Adult assembly required
- Adult supervision required at all times
- Ages 3+




Pole A -24 Pcs



Pole B -24 Pcs



Fabric Cover



Padded Mat




Strap -6 Pcs



Connector Tubes -24 Pcs



Connector Tubes -6 Pcs







Connector Tubes -6 Pcs



Connector Tubes

⚠ Please tightly insert the rods into the connectors, or the fabric cover might not fit.






x 12

4


Use connector tube #1 to connect two poles B together, a total of 12 groups.



x 6





5


Follow the picture to connect poles assembled in step 4 with the longest end of connector #2.




6

Follow the picture to vertically insert the poles assembled in step 5 on the frame bottom.






Follow the picture to fix the fabric cover **C** on the frame.



Follow the picture to tie the inside rope to connector tubes **2** .



Follow the picture to tie the curtain to the pole of the tent with the strap **E** .

