


How to install Aobio Printer driver for Windows

1. Double click "Aobio-Windows-Driver-Latest" to install.



2. Then, "Add Printer Successfully!" appears.

