



How to change the setting of the printer and how to define label size (Priview) for Mac

Aobio X4 is default to common size of 4"x6"(102 mm x 152 mm)setting. When printing your file ensure "paper size" is set correctly for your label, If you print other sizes labels, please set as follows:


1. Open a PDF file (any document file is ok), Select "File" → "Print" .



2. Choose "100 mm x 150 mm" under "Paper Size " drop down menu.



3. Select "Printer Features", then you can change the setting of printer, for example: Speed, Darkness...



4. Select "Print Options 2", then you can change the setting of printer, for example: Horizontal, Vertical, Feed after Print.

