
## How to change the setting of the printer and how to define label size(Priview)for Windows

## Take Win 10 as example:


1.Open your printer page Control Panel → Hardware and Sound → Devices and Printers.




2. Right Click on you newly installed printer "Aobio X4", choose Printing preferences.



3.Click "Page Setup" and choose the size of your label from the drop down menu, Ensure "Name" is set correctly.



4.If your label size is not included in "Name", click "New" to create new Paper Setting.



5.Click "Apply" and "OK", then please remember to run "Intelligent Label Study", every time you change your label size, you need to do that.

