

YUNZII®

AL66



www.yunzii.com
support@yunzii.com

YUNZII®


AL66

Tri-Mode Wireless with Knob CNC Aluminum Customized Mechanical Keyboard

Content List:

1. AL66 Aluminum Keyboard x1
2. USB Cable for TYPE-C x1
3. Keycap and Switch Puller x1
4. Warranty Manual x1
5. 2.4G Wireless Receiver x1

2.4G Wireless Receiver Connection:



Switch the mode button to 2.4G Mode. Then long press FN+R=2.4G, and the indicator light blinks blue. Plug the 2.4G receiver into the computer USB port, then it will pair and install the compatible program automatically. The indicator light will stay on when paired successfully.

Quick Start Guide:




USB Cable for TYPE-C 2.4G Wireless Receiver



AL66 Aluminum Keyboard

USB Cable Connection:



Switch the mode button to the middle Wired Mode. When the cable is plugged in, the keyboard will connect with the computer automatically, then it is ready for usage.

YUNZII AL66 Keyboard On-Off Manual:



- 1 2.4G Receiver Port
- 2 TYPE-C Port
- 3 Tri-Mode Switch Between Bluetooth, Wired and 2.4G Wireless
- 4 Switch for MacOS and Windows Mode


Charging:

Charge the keyboard by connecting the original charging cable to the computer USB port, or using a DC-5V charger. Note the direction of the TYPE-C cable and insert it carefully. The RGB will light red when charged and will go off when fully charged.

Compatible System:

The AL66 keyboard supports Windows2000, WindowsXP, Vista Win7, Win8, Win10, Win11, MacOS and mobile phone systems.

Bluetooth Connection:



Switch the mode button to Bluetooth Mode. Then long press FN+Q=BT1, and the indicator light blinks green. Press FN+W=BT2, and the indicator light blinks pink. Press FN+E=BT3, and the indicator light blinks yellow.

Quick Start Guide of FN key combination:

FN + F1	Screen Brightness ↓	FN + F9	Stop
FN + F2	Screen Brightness ↑	FN + F10	Mute
FN + F3	Calculator	FN + F11	Volume Down
FN + F4	Computer	FN + F12	Volume Up
FN + F5	Player	FN + Q	Bluetooth Channel 1
FN + F6	Previous Song	FN + W	Bluetooth Channel 2
FN + F7	Next Song	FN + E	Bluetooth Channel 3
FN + F8	Pause/Play	FN + R	2.4G

Quick Start Guide of RGB Settings:

FN + []	Change Backlight Effect	FN + []	White Light ON/OFF
FN + [↑]	Brightness Up	FN + []	Battery
FN + [↓]	Brightness Down	FN + []	END
FN + []	Blinking Speed ↑	FN + []	Backlight Effects ON/OFF
FN + []	Blinking Speed ↓	FN + []	Reset
FN + []	Change Backlight Color	FN + []	Lock Win

Double-press the FN Key, change the ESC, 1, 2, 3, 4, 5, 6, 7, 8, 9, 0, -, to <F1-F12>, "="+ key change to "~" key, "DEL" key change to "Home", FN+Home=END.

www.yunzii.com
support@yunzii.com



YUNZII®

AL66


三模CNC铝制客制化机械键盘

Tri-Mode Wireless CNC Aluminum Customized Mechanical Keyboard

内容清单:

1. AL66键盘x1
2. TYPE-C数据线x1
3. 拔轴拔键二合一工具x1
4. 保修卡说明书x1
5. 2.4G接收器x1

接收器2.4G连接:




把键盘的模式切换开关打到2.4G位置，长按FN+R=2.4G，这时键盘模式灯会快闪蓝色灯光，那就要把接收器插到电脑空闲的USB端口上，这时电脑会自动对码并安装好相应适配软件，安装完成并可以使用，这时的键盘对码灯会长亮。

快速上手指南:



数据线接头连接示意图:



用自带的TYPE-C线同电脑连接，在插好线的状态下，把键盘的模式切换开关打在中间有线模式位置，这时键盘会同电脑自动连接并安装完成可以使用，这说明键盘同电脑TYPE-C线连接成功可以使用了。

YUNZII AL66机械键盘开关说明:



- ① 2.4G接收器放置孔
- ② 蓝牙-有线-2.4G三模式切换开关
- ③ TYPE-C连接端口
- ④ Mac与Win系统切换开关

充电:

用产品自带的充电线连接电脑USB端口或DC-5V充电器对键盘进行充电。充电时要观察连接线TYPE-C头的方向小心插进键盘的充电座内。当插好通电时键盘模式指示灯会亮红色灯，充满电时灯会自动熄灭。

兼容系统:


可运行于电脑Windows2000, WindowsXP, Vista Win7, Win8, Win10, Win11, MacOS及带蓝牙版本的手手机系统

Win系统Fn组合键快速操作说明:

[FN] + [F1] 屏暗	[FN] + [F9] 停止
[FN] + [F2] 屏亮	[FN] + [F10] 静音
[FN] + [F3] 计算器	[FN] + [F11] 音量减
[FN] + [F4] 电脑	[FN] + [F12] 音量加
[FN] + [F5] 播放器	[FN] + [Q] 蓝牙1
[FN] + [F6] 上一曲	[FN] + [W] 蓝牙2
[FN] + [F7] 下一曲	[FN] + [E] 蓝牙3
[FN] + [F8] 播放/暂停	[FN] + [R] 2.4G

双击FN转码: ESC.1.2.3.4.5.6.7.8.9.0~; "+="键转码成""; F1-F12键, 按Shift+"~"-键。DEL键转码成Home键, 再按FN+Home=END。

蓝牙连接:



把键盘的模式开关打到BT位置，再长按FN+Q=BT1，这时键盘模式灯会快闪青色灯光，长按FN+W=BT2，键盘模式灯会快闪粉色灯光，长按FN+E=BT3，键盘模式灯会快闪黄色灯光，当蓝牙对码连好时灯光会长亮，产品采用三通道蓝牙对连方式进行智能识别蓝牙3.0-5.0标准通信。

Fn灯光快速操作说明:

[FN] + [I] 切换灯光模式	[FN] + [TAB] 一键白光
[FN] + [↑] 灯光亮度加	[FN] + [ALT] 电量查询
[FN] + [↓] 灯光亮度减	[FN] + [END] 一键关灯
[FN] + [→] 灯光速度加	[FN] + [Backspace] 一键开关灯光
[FN] + [←] 灯光速度减	
[FN] + [CAP] 灯光复位	
[FN] + [ENTER] 灯光颜色切换	
[FN] + [Win] 锁Win	



www.yunzll.com
support@yunzll.com

YUNZII®


AL66

ノブ付き3モードワイヤレスキーボード
CNCアルミカスタムメカニカルキーボード

内容一覧:

1. AL66 アルミキーボード x1
2. TYPE-C用USBケーブル x1
3. キーキャップ&スイッチプラー x1
4. 保証書 x1
5. 2.4Gワイヤレスレシーバー x1

2.4Gワイヤレスレシーバー接続:




モードボタンを2.4Gモードに切り替えます。FN+R=2.4Gを長押しすると、インジケータライトが青く点滅します。2.4GレシーバーをコンピュータのUSBポートに差し込むと、自動的にペアリングされ、互換性のあるプログラムがインストールされます。ペアリングに成功すると、インジケータライトが点灯したままになります。

クイックスタートガイド:




TYPE-C用USBケーブル

2.4Gワイヤレスレシーバー




AL66アルミキーボード

USBケーブル接続:



モードボタンを中央の有線モードに切り替えます。ケーブルが接続されるとキーボードは自動的にコンピュータに接続され、使用できるようになります。

YUNZII AL66 キーボードスイッチについての説明:



1. 2.4Gレシーバーポート
2. TYPE-Cポート
3. Bluetooth、有線、2.4Gワイヤレス三つモードのスイッチ
4. MacOS/Windowsモードの切り替え

充電:

オリジナル充電ケーブルをコンピュータのUSBポートに接続するか、DC-5V充電器を使用してキーボードを充電します。TYPE-Cケーブルの向きに注意し、慎重に挿入してください。RGBは充電されると赤く点灯し、満充電になると消灯します。

対応システム:


AL66キーボードはWindows2000、WindowsXP、Vista Win7、Win8、Win10、Win11、MacOSおよび携帯電話システムをサポートしています。

FNキーの組み合わせのクイックスタートガイド:

FN + F1 画面の明るさ↓	FN + F9 停止
FN + F2 画面の明るさ↑	FN + F10 ミュート
FN + F3 電卓	FN + F11 ポリウムダウン
FN + F4 コンピュータ	FN + F12 ポリウムアップ
FN + F5 プレーヤー	FN + Q Bluetoothチャンネル1
FN + F6 前の曲	FN + W Bluetoothチャンネル2
FN + F7 次の曲	FN + E Bluetoothチャンネル3
FN + F8 一時停止/再生	FN + R 2.4G

FNキーを2回押し、ESC、1、2、3、4、5、6、7、8、9、0、-を<F1-F12>に変更。
"+=<キーを"> -"キーに変更、"DEL"キーを"Home"に変更、FN+Home=END。

Bluetooth接続:



「モードボタンをBluetoothモードに切り替えます。次にFN+Q=BT1を長押しすると、インジケータランプが緑色に点滅します。FN+W=BT2を押すと、インジケータランプがピンク色に点滅します。FN+E=BT3を押すと、インジケータランプが黄色に点滅します。ペアリングに成功すると、インジケータライトは点灯したままになります。キーボードはBluetooth 3.0-5.0標準の通信を3つのチャンネルでインテリジェントに識別します。」

RGB設定のクイックスタートガイド:

FN + [] バックライト効果の変更	FN + TAB ホワイトライトON/OFF
FN + ↑ 明るさアップ	FN + [] バッテリー
FN + ↓ 明るさダウン	FN + [] 終了
FN + → 点滅速度↑	FN + [BACKSPACE] バックライトエフェクトON/OFF
FN + ← 点滅速度↓	
FN + CAP リセット	
FN + ENTER バックライト色の変更	
FN + Win ロックウィン	



www.yunzll.com
support@yunzll.com