

1301 Module

Housing-Module

HS5000-1



HS5000-4



HS5000-2



HS5000-5



HS5000-3



HS5000-6



Order notes to our customers: The default parameters are as follows. For special needs, please contact sales.

- 1) Connector FC/APC, 900 um, 1 m by default for all devices except for high power devices.
- 2) Slow axis working, fast axis blocked, connector key is aligned to slow axis by default for PM devices.

1301 Module

Housing-Module

HS5000-7



HS5000-10



HS5000-8



HS5000-11



HS5000-9



HS5000-12



Order notes to our customers: The default parameters are as follows. For special needs, please contact sales.
1) Connector FC/APC, 900 um, 1 m by default for all devices except for high power devices.
2) Slow axis working, fast axis blocked, connector key is aligned to slow axis by default for PM devices.