


IPS Clock Software Tutorial

WELCOME

Thank you very much for buying the new IPS Clock. Please read this tutorial before using the clock in order to get the most out of all the features and functions.

Please read these instructions for first time use. Setting the time requires a computer running the EleksTube IPS client to set up the Wi-Fi . after the WiFi configuration is successful, the clock will automatically get the network time.

 **Warning** : The PC client "EleksTube IPS.exe" must be installed on a computer with Win10 or above.

Function Catalog

- Download 2
- Preparation 5
- Operation..... 6
 - Language 6
 - Time 7
 - Synchronize the Local Time 7
 - Switch Time Zones..... 8
 - Switch Time Format 9
- Backlight..... 10
 - Change Backlight Mode, Turn off/on Backlight..... 10
- Dials 11
 - Dials Market 11
 - Upload Pictures 12

Download


*"EleksTube IPS.exe" must be installed with Win10 or above. Please check your PC system before downloading the client.

1. Download Address:

<https://drive.google.com/drive/folders/1F7ZKIfNr0Kro3jo-n8lICeQ-CZDjNGhT>

2. Please download the zip file with the file name "EleksTube IPS NTP NEW 20220625.zip".

3. After downloading, double click "EleksTube IPS.exe" to open the client. Use Type-C cable to connect the clock.



A key: Short Click - Show date

Long - Professional mode

B key: Short Click - Switch style

Long - Backlight on/off


C key: Short Click - Albums mode

Long - 12/24H switch

D key: Short Click - Sleeping mode

Long - Reboot


Back of clock



Note: When installing the screen, please note that the side with the components attached is the back, the screen will not be damaged but will be black screen can not start.

Elek

Preparation




1. Click **Network SET**.
2. Enter your current 2.4G Wi-Fi username in "WIFI SSID" (5G network is not supported).
3. Enter the corresponding Wi-Fi password in "WIFI PSW".
4. Click **Save Settings**.
5. Click **Device INFO** to confirm the "Network status" status as: connected.

Operation


Language




1. Click  to switch the language.


Time

Synchronize the Local Time



1. Click  to synchronize the time on the clock with the PC time.

Switch Time Zones



1. Click **Network SET**.
2. Enter your current 2.4G Wi-Fi username in "WIFI SSID" (5G network is not supported).
3. Enter the corresponding Wi-Fi password in "WIFI PSW".
4. Select the time zone in the drop-down checkbox.
5. Click "Save Settings".

Switch Time Format



1. Click  to switch time format.

Backlight

Change Backlight Mode, Turn off/on Backlight



1&2: Click the color you like.


3: Drag the button to adjust the backlight brightness.

4: Click the mode button to switch the backlight mode.

5: Click  to turn on/off the backlight.

Dials

Dials Market



1. Click **More styles**.
2. Select the dials you want to sync to the clock (no more than 5).
3. Click **Upload**.

Upload Pictures

- Before uploading, make sure the dials images are within following requirements:

(1) Images format: JPG/PNG/BMP 24bit;




(2) Images resolution: 135x240pt;

(3) Rename images from 0–9;

(4) There are no files or sub-folders other than 0–9 images

in the folder, as follows.

- Upload

1. Click 
2. Click  , select the folder where the pictures are stored.
3. Click  .



