




TABK400

User Manual 12.9inch Ipad Keyboard Case With Trackpad


support@protoarc.com
www.protoarc.com
United States: (+1) 866-287-6188
Monday-Friday: 10am-1pm, 2pm-7pm (Eastern Time)*Closed during Holidays

Product Features




- Power Button
- Low Battery: Red Indicator Light
Charging: Orange Indicator Light
Fully Charged: Green Indicator Light
- Bluetooth connection: Blue Indicator Light
Power Indicator: Blue Indicator Light

Bluetooth Connection Instructions




Unfold the keyboard and securely attach the back of the iPad tablet to the magnetic casing of the keyboard.




Power On: Press the power button for 2 seconds or more to activate the keyboard. The blue pairing indicator light and power indicator light will stay on for 3 seconds, then turn off, and the dynamic backlight will be activated. The keyboard is now ready for use.

Power Off: Press the power button for 2 seconds or more to turn off the keyboard. The backlight and all indicator lights will turn off, and the keyboard will stop functioning.



Bluetooth Pairing: Press and hold the Pairing button (usually denoted as "fn" + "B") for 3 seconds. The Bluetooth pairing blue light will start flashing slowly. The pairing process lasts for 120 seconds. Once the pairing is successful, the blue light will turn off. If the pairing is not successful, after 120 seconds, the backlight and other indicator lights will all turn off, and the keyboard will enter sleep mode. Press any key to wake up the keyboard, and then proceed with the pairing process again.



4. Enable the Bluetooth setting switch on your tablet and locate the "ProtoArc TABK400" in the Bluetooth settings. Click on it to initiate pairing and establish a successful connection.

Tips:

- For initial use, press the power button on the keyboard for 2 seconds to turn it on. The Bluetooth indicator light and the power indicator light will both illuminate for 3 seconds and then turn off, activating the dynamic backlight. The keyboard will automatically enter Bluetooth pairing mode.
- To restore default settings: Simultaneously press and hold the C+R+L keys for more than 3 seconds. The two blue lights will flash slowly three times together. The keyboard will automatically clear the historical pairing information and enter the factory default state.

Introduction to Multimedia Key Functions

| Keys | Functions |
|------|--|
| | Decrease screen brightness |
| | Increase screen brightness |
| | Switch to multitasking window |
| | Activate the virtual keyboard |
| | Enable dictation function (when dictation is turned on on the tablet). Long press for 1 second to activate Siri function |
| | Switch backlight brightness among 4 levels (high-medium-low-off). Default is high brightness |
| | Switch backlight effect among 12 options |
| | Previous track |
| | Play/Pause |
| | Next track |
| | Decrease volume |
| | Increase volume |
| | Lock and unlock screen |
| | Switch language. Long press for 2 seconds to access the tablet system menu. Combining FN with other keys enables additional functions listed in the combination chart. |

| Keys | Functions |
|------|---|
| | Press the Pairing button (usually denoted as "fn" + "B") for 3 seconds to perform Bluetooth search. |
| | Up arrow key. |
| | Combining with , it moves to the beginning of the current input character. |
| | Down arrow key. |
| | Combining with , it moves to the end of the current input character. |
| | Left arrow key. |
| | Combining with , it moves to the beginning of the current input line. |
| | Combining with , it moves to the end of the current input line. |

Touchpad Gestures

- Single-finger tap:** Functions as the left mouse button.
- Two-finger click:** Functions as the right mouse button.
- Two-finger swipe up/down:** Functions as the mouse scroll wheel.
- Two-finger swipe left/right:** Switches between desktop pages.


Keyboard Charging

- Two-finger pinch/spread:** Zoom in/out.
- Three-finger slow swipe up:** Switches to the recent tasks window. When the cursor is on a relevant window, a two-finger upward swipe can delete the most recent task window.
- Three-finger fast swipe up:** Returns to the main interface.
- Three-finger swipe left/right:** Switches between active windows.

Tip: The touchpad will not work when a keyboard key is pressed. Release the key to use the touchpad.

Keyboard Charging

- When the battery is low, the low battery indicator light will start flashing red until the keyboard shuts down.
- Plug the USB-A end into the computer interface and the Type-C end into the keyboard to charge. The orange indicator light will remain solid during charging.
- It takes approximately 1 to 2 hours for a full charging cycle. Once the keyboard is fully charged, the charging indicator light will automatically turn green.



Product Specifications

| | |
|---------------------------|--|
| Bluetooth Connection Name | ProtoArc TABK400 |
| Battery Capacity | 800mAh |
| Backlight Sleep Time | 90 seconds |
| Deep Sleep | 10 minutes |
| Battery Life | 9.3 hours(Backlight On), 266 hours (Backlight Off) |
| Working Current | Backlight On: <86mA; Backlight Off: <3mA |
| Sleep Current | <50uA |
| Charging Time | <2Houer |
| Input Power Parameters | DC 5V 1A |
| Wake Up Way | Press any key |
| Weight | 895±10g |
| Keyboard Dimension | 284*240*20mm |

Sleep Mode

- When the keyboard remains idle for more than 90 seconds, it will automatically enter sleep mode, and the keyboard backlight and its indicator lights will turn off. When the keyboard remains idle for more than 10 minutes, it will automatically enter deep sleep mode.
- To wake up the keyboard, simply press any key on the keyboard, and it will be ready within 3 seconds. The indicator light will light up again.

FAQ

- Unable to connect, keyboard not working?
 - Please charge the keyboard immediately.
 - Delete the history of connected devices in the Bluetooth settings of your iPad tablet. After resetting the Touch Keyboard by pressing and holding C+R+L, turn on the Bluetooth switch in the iPad settings again and find the Bluetooth name "ProtoArc TABK400" to re-establish the connection.
 - If the issue persists, try restarting your iPad and follow the instructions in the manual to attempt the Bluetooth connection again.
- Touchpad not responsive?
 - The product is designed to prevent accidental touches (the touchpad does not work when the keyboard keys are pressed; it becomes active after releasing the keys for 500ms). This phenomenon is normal.
 - Please open the touch gesture settings for the Touch Keyboard - Settings - General Gestures. You can also adjust the tracking speed of the touchpad.

Packing List

- WirelessKeyboard * 1
- Type C Charging Cable * 1
- User Manual * 1
- Quick Start Guide * 1