




RELI

Reli Light Cam D1


User Guide

Introduction



2

Introduction



3

Setup

- 1. Download the Reli app**
The camera is only compatible with the Reli app, please set up and manage your device through the Reli app. The Reli app can be downloaded through App Store or Google Play by searching Reli.
- 2. Set up and connect your camera**
Open the Reli app and swipe right on the home page, tap "Add a new device" on the top of the device page. Add Devices > Reli Light Cam D1 > Choose a method to connect the camera. Then follow the in-app instructions to finish connection.
- 3. Let's get started!**
After setup, tap the live button in the app to see the video from your camera.

4

Installed on the wall

- 1. Using self-tapping screws**
(This method is suitable for cement walls or similar surfaces.)
 - Select a suitable installation location, stick the install paper and use an impact drill to drill two holes with a diameter of approximately 6 mm. Insert the 2 expansion tubes into each hole, respectively.
 - Fix the mounting bracket to the wall with the self-tapping screws.

5

- Place the camera on the wall mounting bracket and tighten the bottom screw.
-
- Note: Please use the included expansion tubes and self-tapping screws for installation.

6

Installed on the wall

- 2. Using double-sided tape**
(This method is suitable for smooth marble, wooden or metallic surfaces.)
 - Clean the installation location so that it is flat, smooth, and dust-free.
 - Peel off the release liner from the double-sided tape and stick the mounting bracket on the selected location, press down firmly on the mounting bracket for 30 seconds to ensure it is installed securely.

7

- Place the camera on the mounting bracket and tighten the bottom screw.
-
- 3. Adjust the camera angle**
 - After installing the camera, tap the live button to see if the angle is suitable.
 - The horizontal viewing angle of the camera can be adjusted by adjusting the tightness of the screw. Then fasten the screw to lock the position of the camera.

8

Where you can use D1

(Accessories need to be purchased additionally)

- 1. Installed in the yard**
 - Connect the camera and the ground stand through the nut at the bottom of the camera.
 - Face the camera to the area you want to monitor.
 - Insert the stand into the ground.

9

Where you can use D1

(Accessories need to be purchased additionally)

- 2. Installed on a tree**
 - Connect the camera and the strap mount through the nut at the back of the camera.
 - Wrap the strap mount around a branch.
 - Tighten the strap mount.

10

Where you can use D1

(Accessories need to be purchased additionally)

- 3. Installed on a baby's crib**
 - Connect the camera and the tripod bracket through the nut at the back of the camera.
 - Secure the bracket.

Note: We do recommend to turn off the spotlight when facing the babies.

11

Where you can use D1

(Accessories need to be purchased additionally)

- 4. Installed on a table**
 - Connect the camera and the desk and fence stand through the nut at the bottom of the camera.
 - Clip the clip to the edge of the table or fence.
 - The angle can be adjusted by bending the rod.

12

Lights

- Charging light**
- Red light: charging
 - Green light: charging completed
- Status light**
- Flashing yellow light: waiting for connection
 - Solid blue light: connected

13

Power on, reset, or power off your device

- Power on your device**
Press and hold the Power button until your device says it is powered on.
- Reset your device**
Make sure your device is powered on, press and hold the Power button until your device prompts that reset successfully.
- Power off your device**
Flick the Power button and your device will prompt that it is shutting down.

What's in the box

Reli Light Cam D1, Wall Mounting Bracket, Screws*2, Expansion Tubes*2, Charging Cable, User Guide, Prompt Sticker, Installation Paper, Double-sided Tape.

14

Specifications

Name:	Reli Light Cam D1
Model:	FJ11HWXJ
Battery Capacity:	7800 mAh(TYP)
Rated Input:	Max 5V = 2A
Resolution:	1920*1080
Lens Viewing Angle:	155°
Storage:	Cloud storage, SD card
Audio System:	Two-way audio
Night Vision Lights:	4 × 850 nm infrared lights
Operating Temperature:	-20℃~50℃ (-4℉~122℉)
Operating Humidity:	10%~90%RH, non-condensing
Compatible with:	Android 9.0, iOS12.0 or above
Wireless Connectivity:	Wi-Fi IEEE 802.11 b/g/n 2.4GHz

15

Precautions

- The camera only supports 2.4 GHz wireless networks.
 - Please install the camera in areas within the range of the Wi-Fi coverage, and try to place the camera where the Wi-Fi signal is strong.
 - Avoid exposing the lens to direct sunlight to prevent recording abnormal images.
 - When enabling or disabling night vision, the infrared cut-off filter is switched, and the camera makes a slight clicking sound. This is normal.
 - This camera is for residential use only, do not use it for illegal purposes.
- Illustrations of the product, accessories, and user interface in the user manual are only for reference purposes. The actual product and functions may vary due to product enhancements.
 - Please use the original charging cable, other charging cables may cause charging failure and water ingress to the device.

16

WEEE information:

All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

17

Warning:

- Only use batteries approved by the manufacturer. Replacement of the wrong type of battery may result in failure of safety protection and risk of explosion, fire, etc.
 - Do not put the battery in an extremely high-temperature environment, such as sunshine, fire, microwave oven, oven, etc. High temperatures may cause an explosion or leakage of flammable liquid or gas.
 - Do not disassemble, squeeze or cut the battery. It may cause an explosion.
 - Do not place the battery at extremely low pressure, which may cause the battery to explode or leak flammable liquids and gases.
 - Do not continue to use the battery if it is severely swollen.
 - Do not swallow batteries, which can cause chemical burns.
- If you think the battery may have been swallowed or placed in any part of the body, seek medical help immediately.
 - If the battery compartment is not securely closed, discontinue using the product and keep it away from children.
 - Keep children away from new and used batteries.
 - Please do not throw the battery anywhere. Please comply with the relevant national regulations, the safe disposal of used batteries.
 - If this product contains button batteries, do not swallow. Swallowed button batteries can cause severe internal burns and potentially death within 2 hours.

18

Warning:

Hereby, Reli Technologies LLC declares that the radio equipment type FJ11HWXJ is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following website: <https://www.reliup.com>

FCC Verification:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

20

Reli Technologies LLC
919 N Market St Suite 950, Wilmington, DE 19801
Contact us: service@reliup.com
www.reliup.com

21

More than security