

(1) Base	(2) Gas Column	(3) Mechanism	<p>A</p>	<p>B</p>
(4) Castor	(5) Armrest	(6) Seat	<p>C</p>	<p>D</p>
(7) Back		(8) Headrest	<p>E</p>	
<p>(9) Spare Parts</p> <ul style="list-style-type: none"> 1. X4 6X20MM 2. X6 6X30MM 3. X2 6X25MM 4. X3 8X40MM 5. X10 6X16MM 6. X1 6MM 				